

AMS 6500 ATG

A6500-TP Temperature Process Card



Copyright

© 2025, Emerson. All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means without the written permission of Emerson.

Disclaimer

This manual is provided for informational purposes. EMERSON MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Emerson shall not be liable for errors, omissions, or inconsistencies that may be contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material. Information in this document is subject to change without notice and does not represent a commitment on the part of Emerson. The information in this manual is not all-inclusive and cannot cover all unique situations.

Patents

The product(s) described in this manual are covered under existing and pending patents.

Vermerk zur Installation der Messketten in explosionsgefährdeter Umgebung.



Soll die Messkette in explosionsgefährdeter Umgebung installiert werden, so ist auf die Einhaltung der in der Gebrauchsanweisung enthaltenen Installationshinweise zu achten. Sollten dabei sprachliche Schwierigkeiten auftreten, wenden Sie sich bitte an die Herstellerfirma, sie wird Ihnen eine Übersetzung der relevanten Artikel in der Landessprache des Verwendungslandes zukommen lassen.



Nota fuq l-installazzjoni tal-ktajjen tal-kejl f'ambjent esploživ

Jekk il-katina tal-kejl suppost li tigi installata f'ambjent esploživ, hu importanti li ssegwi l-istruzzjonijiet pertinenti tal-manwal. Jekk issib xi diffikultà bil-lingwa, jekk joghgbok ikkuntattja lill-manifattur biex tikseb traduzz-joni tal-paragrafi rilevanti fil-lingwa mehtiega.



Anmärkning beträffande installation av mätkedjorna i explosionsfarlig miljö.

Ska mätkedjan installeras i explosionsfarlig miljö, måste de anvisningar följas som ges i instruktionsboken beträffande installationen. Skulle därvid språkproblem uppstå, ber vi dig kontakta det tillverkande företaget som då kommer att sända dig en översättning av de relevanta artiklarna på användningslandets språk.



Opomba za namestitev merilne verige v eksplozivno ogroženem okolju

Èe se merilna veriga namešèa v eksplozivno ogroženem okolju, je potrebno upoštevati namestitvena opozorila, ki so v Navodilih za uporabo. Èe se pri tem pojavi jozikovne težave, se posvetujte z izdelovalcem; poslali vam bodo prevod ustreznih èlankov v jeziku države, kjer se naprava uporablja.



ZáZNAM k inštalácii meracích reťazcov vo výbušnom prostredí

Ak má byť merací reťazec inštalovaný vo výbušnom prostredí, treba dbať na dodržiavanie pokynov k inštalácii, uvedených v návode na použitie. V prípade, že by sa pritom vyskytli jazykové problémy, obráťte sa prosím na výrobcu, ktorý Vám zašle preklad relevantných èlánkov v jazyku Vašej krajiny.



Nota referente à instalação de cadeias de agrimensor em ambientes potencialmente explosivos

Caso a cadeia de agrimensor deva ser instalada em um ambiente potencialmente explosivo, é imprescindível observar e cumprir as indicações de instalação das instruções de serviço. Caso tenha dificuldades idiomáticas, queira entrar em contato com a firma produtora, esta poderá enviar-lhe uma tradução dos capítulos mais importantes no idioma do país onde o produto deverá ser empregado.



Wskazówka dotycząca instalacji łańcuchów mierniczych w otoczeniach zagrożonych eksplozją.

Jeżeli łańcuch mierniczy ma być zainstalowany w otoczeniu zagrożonym eksplozją, należy uwzględnić wskazówki dotyczące instalacji, które są zawarte w instrukcji obsługi. Jeżeli w trakcie lektury wystąpią jakiekolwiek problemy związane ze zrozumieniem tekstu, prosimy zwrócić się do producenta, który chętnie wykona tłumaczenie wybranych części dokumentacji na język danego kraju.

Opmerking m.b.t. installatie van elektrische meet circuits in explosiegevaarlijke omgeving



Dient de installatie van elektrische meet circuits in een explosiegevaarlijke omgeving te geschieden, moet men toeziен dat de in de gebruikshandleiding opgenomen installatieinstructies worden nageleefd. Bij taalkundige problemen gelieve contact op te nemen met de fabrikant, deze zal u vervolgens een vertaling in de taal van het gebruiksland doen toekomen.



Pastaba dėl matavimo grandinės įrengimo sprogimo atžvilgiu pavojingoje aplinkoje

Jei matavimo grandinė turi būti įrengta sprogimo atžvilgiu pavojingoje aplinkoje, privaloma laikytis vartotojo instrukcijoje pateiktų įrengimo nurodymų. Jei kiltų sunkumų dėl kalbos, prašome kreiptis į gamintojo įmonę, kuri pateiks Jums reikiamą skyriaus vertimą į vartotojo valstybės kalbą.

Nota sull'installazione delle catene per misurazione in ambienti a rischio di esplosioni



Nel caso in cui si debbano installare le catene per misurazione in ambienti a rischio di esplosioni, è necessario attenersi alle avvertenze per l'installazione contenute nelle istruzioni d'uso. Per difficoltà di carattere linguistico, rivolgetevi alla ditta produttrice. Quest'ultima Vi farà pervenire una traduzione degli articoli rilevanti nella lingua del paese d'impiego.



Megjegyzés a mérőláncok robbanásveszélyes környezetben történő szereléséhez.

Ha a mérőláncot robbanásveszélyes környezetben kell felszerelni, akkor ügyeljen a Használati útmutatóban közölt szerelési utasítások betartására. Amennyiben nyelvi nehézségek merülnek fel, szíveskedjen a gyártó céghöz fordulni, amely elküldni Önnek a felhasználó ország nyelvére lefordított, erre vonatkozó cikket.

Remarque concernant l'installation des chaînes de mesure dans un environnement présentant un risque d'explosion



Si la chaîne de mesure doit être installée dans un environnement présentant un risque d'explosion, il est impératif de veiller à respecter les consignes d'installation contenues dans les instructions de service. S'il devait ce faisant surgir des problèmes linguistiques, veuillez vous adresser à la société fabricante: elle vous fera parvenir une traduction des articles significatifs dans la langue du pays de mise en oeuvre.



Huomautus mittausketjun asentamisesta räjähdyssaltilissa ympäristössä

Jos mittausketju tulee asentaa räjähdyssaltilissa ympäristössä, on käyttöohjeessa annettuja asennusohjeita noudatettava. Jos käyttöohjeessa käytetty kieli aiheuttaa ongelmia, kääntykää valmistajayrityksen puoleen. Se toimittaa käyttöönne tarvittavat artikkelit käyttömaan viralliselle kielelle käännettynä.



Juhend mõõdukettide ülespanemiseks plahvatusohtlikus piirkonnas.

Kui panna üles mõõdukettid plahvatusohtlikkus piirkonnas, nii tuleb jälgida kasutusjuhendis sisaldatud instalationimärkmeid. Juhul kui tekkivad raskused keelega, siis pöörduge palun tootja poole. Tootja saadab emakeelse tõlgje vastavalt artiklile ning maale.



Notas sobre la instalación de cadenas de medición en un entorno potencialmente explosivo.

Si ha de instalar la cadena de medición en un entorno potencialmente explosivo, deberá respetar las indicaciones sobre la instalación, contenidas en el manual de uso. Si surgieran dificultades lingüísticas, póngase en contacto con la empresa fabricante, que le facilitará una traducción del artículo en la lengua del país donde se emplee.



Note on the installation of the measuring chains in an explosive environment

If the measuring chain is supposed to be installed in an explosive environment, it is important to follow the pertinent installation instructions in the manual. Should you encounter difficulties with the language, please contact the manufacturer to obtain a translation of the relevant paragraphs into the language required.



Σημείωση για την εγκατάσταση αλυσίδων μέτρησης σε περιβάλλου, στο οποίο υπάρχει κίνδυνος έκρηξης
Εάν η αλυσίδα μέτρησης πρόκειται υα εγκατασταθεί σε περιβάλλου, στο οποίο υπάρχει κίνδυνος έκρηξης, πρέπει υα τηρηθούν οπωσδίποτε οι οδηγίες εγκατάστασης που περιλαμβάνουται στις οδηγίες Χρήσης. Εάν υπάρχουν γλωσσικές δυσκολίες καταύνησης, παρακαλούμε υα απευθυνθείτε στην κατασκευάστρια εταιρεία, η οποία θα φρουτίσει για την αποστολή μιας μετάφρασης των σχετικών άρθρων στη γλωσσα της Χωρας Χρήσης.



Info vedrørende installation af målekæderne i ekspllosionstruede omgivelser
Hvis målekæden skal installeres i ekspllosionstruede omgivelser, skal installationsanvisningerne i brugsanvisningen følges. Hvis der i denne forbindelse opstår sproglige problemer, bedes De henvende Dem til produktionsfirmaet, som så vil sørge for, at De modtager en oversættelse af den relevante artikel på Deres sprog.



Poznámka k instalaci měřicích řetězců v prostředí s nebezpečím výbuchu.

Když má být měřicí řetězec (sestávající z čidla a konvertoru) instalován v prostředí s nebezpečím výbuchu, tak je třeba respektovat instalační pokyny, které jsou součástí návodu k upotřebení. Kdyby při tom došlo k jazykovým potížím, tak prosíme kontaktujte výrobní firmu, která Vám relevantní článek zašle v jazyku krajiny použití.



Piezīme par mērišanas ļēžu instalēšanu sprādzienā bīstamās zonās.

Ja mērišanas ļēžē jāuzstāda sprādzienbīstamā zonā, ir jāievēro lietošanas instrukcijā dotie instalēšanas norādījumi. Ja rodas kādas valodas grūtības, lūdzu griezieties pie izgatavotāja firmas, kas jums nosūtīs nozīmīgāko nodaļu tulkojumus lietotāja valsts valodā.

Emerson
epro GmbH
Jöbkesweg 3
48599 Gronau
Germany
T +49 2562 709 0
F +49 2562 709 401
www.Emerson.com

Contents

Chapter 1	General.....	7
1.1	Using this manual.....	7
1.2	Symbols.....	7
1.3	Liability and guarantee.....	8
1.4	Incoming goods inspection.....	8
1.5	Technical support.....	8
1.6	Storage and transport.....	9
1.7	Disposal of the device.....	9
1.8	China RoHS Compliance.....	9
1.9	CCC Certification – AMS 6500 ATG.....	10
1.10	Installation awareness.....	10
Chapter 2	Safety instructions.....	11
2.1	Using the device.....	11
2.2	Owner's responsibility.....	11
2.3	Radio interference.....	11
2.4	ESD safety.....	12
Chapter 3	Application and design.....	13
3.1	Application.....	13
3.2	Design.....	13
Chapter 4	Installation.....	16
4.1	Commissioning.....	16
4.2	CSA - General safety.....	16
Chapter 5	Hazardous location installation.....	17
Chapter 6	Configuration.....	18
6.1	General configuration procedure.....	18
6.1.1	Offline configuration overview.....	18
6.1.2	Online configuration overview.....	19
6.2	Start of an offline card configuration.....	22
6.3	Start of an online card configuration.....	23
6.4	Configuration of an already existing card.....	24
6.5	Configuration editor and parameters.....	24
6.5.1	Ribbon command bar.....	25
6.5.2	Basic.....	31
6.5.3	Sensor input.....	32
6.5.4	Cold junction compensation	39
6.5.5	Digital inputs.....	43
6.5.6	Calculation.....	44

6.5.7 Current outputs.....	46
6.5.8 Digital outputs.....	48
6.6 Send and reload a configuration.....	53
6.6.1 Send a configuration	53
6.6.2 Reload a configuration.....	55
Chapter 7 Online View.....	56
7.1 Overview.....	57
7.2 Details.....	61
7.3 Live data.....	63
7.4 Online commands.....	65
7.5 LEDs on the front panel.....	67
Chapter 8 Applications and functions.....	68
8.1 Electrical temperature measurement.....	68
8.2 Temperature measurement with RTDs.....	68
8.3 Temperature measurement with thermocouples	70
8.4 Measurement of process parameters	73
8.5 Channel OK supervision.....	73
8.6 Bypass.....	75
Chapter 9 Replace a Temperature Process Card.....	77
Chapter 10 Functional check and maintenance.....	78
10.1 Functional check.....	78
10.1.1 Check of the measuring functions	78
10.1.2 Check of thermocouple measurements.....	78
10.1.3 Check of RTD measurements	79
10.1.4 Check of process value measurements	80
10.2 Maintenance.....	80
Chapter 11 Technical data.....	81
11.1 Power supply.....	81
11.2 Signal input.....	81
11.3 Digital input.....	83
11.4 Outputs.....	83
11.5 Data interface.....	84
11.6 Mechanical design and environmental conditions.....	84
Chapter 12 Certificates.....	87
Appendix A Card related system events.....	98
Index	100

1 General

1.1 Using this manual

This manual contains information concerning the use of the device.

Read the operating manual completely before installing and using the device. Comply with all safety instructions.

This operating manual applies for A6500-TP Temperature Process Cards with hardware revisions and software versions listed in [Table 1-1](#).

Table 1-1: Hardware and software revisions

Hardware revision ¹	Firmware version	AMS Machine Studio version
03, 04, 05, 06, 07, 08, and 12 ²	3.2.1 or later ³	4.1

¹ See type plate for revision level.

² Requires AMS Machine Studio version 3.7 or later and firmware version 3.2.0 or later.

³ Requires an A6500-CC with firmware version 3.x or an A6500-CP with firmware version 1.x.

Include the operating manual when transferring the device to third parties.

Note

When requesting technical support, please indicate type and serial number from the type plate.

[Table 1](#) shows a list of documents that are referred to in this operating manual.

Table 1-2: Referenced documents

MHM-97875	Operating Manual A6500-CC Com Card
MHM-97891	Operating Manual A6500-CP Com Card Pro
MHM-97877	Operating Manual A6500-xR System Racks
MHM-97879	Operating Manual AMS Machine Studio - General Functions

1.2 Symbols

Note

This symbol marks passages that contain important information.

⚠ CAUTION

This symbol marks operations that can lead to malfunctions or faulty measurements, but will not damage the device.

⚠ DANGER

A danger indicates actions that can lead to property damage or personal injury.

	According to IEC 61010, this symbol means that this device must be operated with DC voltage.
	According to IEC 61010, this symbol means that the documentation of the device must completely be read and understood before installing and commissioning of the device. Observe all safety related instructions in this document.

1.3

Liability and guarantee

Emerson is not liable for damages that occur due to improper use. Proper use also includes the knowledge of, and compliance with, this document.

Customer changes to the device that have not been expressly approved by Emerson will result in the loss of guarantee.

Due to continuous research and further development, Emerson reserves the right to change technical specifications without notice.

1.4

Incoming goods inspection

Check the content of the shipment to ensure that it is complete; visibly inspect the goods to determine if the device has been damaged during transport. The following parts are included in the scope of delivery and must be contained in the shipment.

- A6500-TP Temperature Process Card
- AMS 6500 ATG Quick User Guide

If the contents are incomplete, or if you observe any defects, file a complaint with the carrier immediately. Inform the responsible Emerson sales organization so your device can be replaced. In this case, attach a tag with customer name and the observed defect.

1.5

Technical support

You may need to ship this product for return, replacement, or repair to an Emerson Product Service Center. Before shipping this product, contact Emerson Product Support to obtain a Return Materials Authorization (RMA) number and receive additional instructions.

Product Support

Emerson provides a variety of ways to reach your Product Support team to get the answers you need when you need them:

Phone

Toll free 1 800 833 8314 (U.S. and Canada)
+1 512 832 3774 (Latin America)

+63 2 8702 1111 (Asia Pacific, Europe, and Middle East)

Email

Guardian.GSC@Emerson.com

Web

<http://www.emerson.com/en-us/contact-us>

To search for documentation, visit <http://www.emerson.com>.

To view toll free numbers for specific countries, visit <http://www.emerson.com/technicalsupport>.

Note

If the equipment has been exposed to a hazardous substance, a Material Safety Data Sheet (MSDS) must be included with the returned materials. An MSDS is required by law to be available to people exposed to specific hazardous substances.

1.6

Storage and transport

Store and transport the device only in its original packaging. Technical data specifies the environmental conditions for storage and transport.

1.7

Disposal of the device

Provided that no repurchase or disposal agreement exists, recycle the following components at appropriate facilities:

- Recyclable metal
- Plastic elements

Sort the remaining components for disposal, based on their condition. National laws or provisions on waste disposal and protection of the environment apply.

Note

Environmental hazards! Electrical waste and electronic components are subject to treatment as special waste and may only be disposed by approved specialized companies.

1.8

China RoHS Compliance

Our products manufactured later than June 30, 2016, and those which are sold in the People's Republic of China are marked with one of the following two logos to indicate the Environmental Friendly Use Period in which it can be used safely under normal operating conditions.

Products that do not have the following marking were either manufactured before June 30, 2026, or are not electrical equipment products (EEP).



Circling arrow symbol with "e": The product contains no hazardous substances over the Maximum Concentration Value and it has an indefinite Environmental Friendly Use Period.



Circling arrow symbol with a number: This product contains certain hazardous substances over the Maximum Concentration Value and it can be used safely under normal operating conditions for the number of years indicated in the symbol. The names and contents of hazardous substances can be found in chapter "Certificates".

1.9

CCC Certification – AMS 6500 ATG

With the announcement of the Chinese market regulation authority SAMR (State Administration for Market Regulation), a Compulsory Product Certification (CCC certification) is mandatory for many explosion protection products. This explosion proof ("Ex") product complies to the CCC obligation and is certified (certification number: 2020322304002386).



This China Compulsory Certificate mark (CCC), is a compulsory safety mark for many products imported, sold, or used in the Chinese market and indicates that the product is certified in accordance to GB/T 3836.1-2021, GB/T 3836.3-2021, and GB/T 3836.8-2021. If the product label is to small to contain the CCC certification mark, it is sufficient to have the mark printed on the minimum package and in the attached document.

1.10

Installation awareness

Note

When planning a measurement, follow these guidelines:

- Consider environmental conditions which might have an influence on the measurement such as temperature, humidity, substances aggressive to the sensor, and pollution.
- Always use a stiff and vibration-free sensor holder.
- Define a suitable measuring range, not larger than necessary, in consultation with the operator of the plant.
- Define the trip limit in consultation with the operator of the plant.
- Take measurement deviations into account when defining trip limits.
- Use a sensor that meets the requirements of the defined measuring range.
- Ensure an EMC-compatible installation including the use of proper cables.
- Ensure proper function of the measurement before activating the measurement in the production environment.

2

Safety instructions

To ensure safe operation, carefully follow all the instructions in this manual.

The correct and safe use of this device requires that both operating and service personnel understand and comply with general safety guidelines and observe the special safety comments listed in this manual. Where necessary, safety-sensitive points on the device are marked.

⚠ DANGER

Because the device is electrical equipment, only specially trained and authorized personnel may commission, service, and maintain this equipment.

2.1

Using the device

Install and use the device as specified in this document.

If the device is used in a manner not specified by the manufacturer, the functions and protection provided by the device may be impaired.

2.2

Owner's responsibility

If there is a reason to suspect that hazard-free operation, and thus, adequate machine protection is no longer possible, take the device out of operation and safeguard it from unintentional operation. This is the case:

- if the device shows visible damage.
- if the device no longer works.
- after any kind of overload that has exceeded the permissible limits (see technical data of the device for permissible limits).

⚠ DANGER

If device tests have to be completed during operation or if the device has to be replaced or decommissioned, it will impair the machine protection and may cause the machine to shut down. Make sure to deactivate machine protection before starting such work, and reactivate it after work has been completed.

2.3

Radio interference

The device is carefully shielded and tested to be technically immune to radio interference and complies with current standards. However, if you operate this device together with other peripheral devices that are not properly shielded against radio interference, disturbances and radio interferences may occur.

2.4

ESD safety

DANGER

Internal components can be damaged or destroyed due to electrostatic discharge (ESD) during the handling of the device.

Take suitable precautions before handling the device to prevent electrostatic discharges through the electronics. Such measures might include, for example, wearing an ESD bracelet. Transport and storage of electronic components may only be made in ESD-safe packaging.

Handle the device with particular care during dry meteorological conditions with relative humidity below 30% as electrostatic discharges can occur more frequently.

3 Application and design

3.1 Application

The A6500-TP Temperature Process Card is a component of the AMS 6500 ATG Machine Protection System. The card is equipped with four measuring channels for temperature measurements with thermocouples or resistance temperature detectors (RTDs) and for measurements of process signals 0 to 1 V, 0 to 10 V, or 0/4 to 20 mA standard signals. Also, the card contains two digital inputs and six digital outputs.

The measured signals are transmitted via the internal RS 485 bus to the communication card and converted to Modbus RTU, Modbus TCP/IP, and OPC UA protocols for further transmission to host computers or analysis systems. In addition, the communication card provides the communication via the USB socket at the front plate for the connection to PC/laptop for the configuration of cards and for visualization of measuring results.

The measuring results can be output via analog outputs 0/4 to 20 mA. These outputs have a common ground and are electrically isolated from the system supply.

The operation of the A6500-TP Temperature Process Card is performed in the A6500-xR racks, which also provides connection of supply voltages and signals.

The A6500-TP Temperature Process Card provides the following functions:


- Temperature measurement with resistance temperature detectors (RTDs)
- Temperature measurement with thermocouples with internal and external cold junction compensation
- Measurement of standard process signals 0 to 1 V, 0 to 10 V, or 0/4 to 20 mA
- Acquisition of digital signals with two digital inputs
- Output of analog values for each measuring channel via four current outputs 0/4 to 20 mA
- Output of alarms via six digital outputs; the assignment to the measuring channels can be configured in any way

3.2 Design

The A6500-TP Temperature Process Card is designed as a standard euro board (100 mm x 160 mm) and has an anodized front plate of 6 HP (approximately 30 mm) width.

Monitors of the AMS 6500 ATG system may be installed in any operating position in standard module frames 19", 3RU height, or any other Intermas compatible systems and housings. This manual describes installation and operation of the A6500-TP Temperature Process Card in the A6500-xR System Racks. [Figure 3-1](#) shows the side view of the card.


Figure 3-1: Side view



- A. Handle - for pulling the monitor from the rack; labeled with the serial number on a small sticker.
- B. Mounting screws
- C. Connector with type plate with designation (PN), serial number (SN), and hardware revision (Rev.).

Figure 3-2 shows the front plate elements.

Figure 3-2: Front view



- A. Handle
- B. Mounting screws
- C. green LED: Card status indication
- D. red LEDs: Alarm status

4 Installation

For installation and mounting of the A6500-xR System Racks, sensor connection, and wiring, see operation manual of the A6500-xR System Racks.

Procedure

1. Select one of the eleven protection card slots 1 to 11.
2. Wire the slot in accordance to the measuring task (sensor connection, digital inputs and outputs, and so on).
3. Push the card into the prepared slot.
4. Secure the card by gently fastening the screws at the front plate.

Note

The AMS 6500-ATG cards are hot-swappable. So, it is not necessary to switch off the power supply of the system rack for installing or replacing cards.

⚠ CAUTION

Any work at the system may impair machine protection.

4.1 Commissioning

Procedure

1. If the card is not configured, create a configuration with AMS Machine Studio, download it to the card (see [Configuration](#)).
2. Ensure proper measurement by checking input and output signals (see [Functional check](#)).

4.2 CSA - General safety

Conditions of acceptability

See chapter "CSA - General safety" of the A6500-xR System Racks operating manual (MHM-97877) for conditions of acceptability.

5

Hazardous location installation

The ex-approval of the A6500-TP Temperature Process Card is only valid if the Temperature Process Card is installed in A6500-xR System Racks. See chapter "Hazardous location installation" of the A6500-xR System Racks operating manual (MHM-97877) for details.

6 Configuration

6.1 General configuration procedure

Use AMS Machine Studio to configure the A6500-TP Temperature Process Card. An online connection through an A6500-CC Com Card or an A6500-CP Com Card Pro is required for the configuration. See operating manual of the communication cards for details. Without an online connection, a created configuration file can later be sent to the A6500-TP card.

Prerequisites

- A6500-CC Com Card or A6500-CP Com Card Pro
- A6500-TP Temperature Process Card installed in an A6500-xR rack
- Power supply
- USB cable with Type-A and Type-B plug or Ethernet cable
- AMS Machine Studio (configuration software)
- PC or laptop with Microsoft Windows 10 Microsoft Windows 11

6.1.1 Offline configuration overview

Procedure

1. Start AMS Machine Studio.
2. Enter configuration parameter according to the measuring task.
3. Save the configuration.
When there is a connection to the system, you can load the saved configuration file to the card (see [Send a saved configuration file to the card](#)).

Send a saved configuration file to the card

Procedure

1. Switch on the power supply of the system if not already on.
2. Connect the laptop to the communication card of the system by using the USB or Ethernet connection.
3. Start AMS Machine Studio.
4. Ethernet connection: Click **Connect ATG-System** to connect to the AMS 6500 ATG system.
5. Only A6500-CP: Log in with an operator or an administrator account.
6. Only A6500-CP: Enable configuration of the card. See [Enable system programming with A6500-CP communication card](#) or [Enable system programming with redundant A6500-CP communication cards](#) if using redundant communication with two A6500-CP Com Cards Pro.
7. Select the card to be configured and click **Configure**.

8. Open the saved configuration file (**File → Open**).
9. Send the configuration to the card.
10. Only A6500-CP: Switch back the key-switch to the locked position to protect the AMS 6500 ATG system against unauthorized changes.
11. Close AMS Machine Studio and disconnect the connection to the communication card.

After these steps, the Temperature Process Card is ready for operation.

6.1.2 Online configuration overview

Procedure

1. Switch on the power supply of the system if not already done.
2. Connect the laptop to the communication card of the system by using the UBS or Ethernet connection.
3. Start AMS Machine Studio.
4. Ethernet connection: Click **Connect ATG-System** to connect to the AMS 6500 ATG system.
5. Only A6500-CP: Log in with an operator or an administrator account.
6. Only A6500-CP: Enable data transfer to the card. See [Enable system programming with A6500-CP communication card](#) or [Enable system programming with redundant A6500-CP communication cards](#) if using redundant communication with two A6500 Com Cards Pro.
7. Select the card to be configured and click **Configure**.
8. Enter the configuration parameters according to the measuring task.
9. Send the configuration to the card.
10. Save the configuration.
11. Only A6500-CP: Switch back the key-switch to the locked position to protect the AMS 6500 ATG system against unauthorized changes.
12. Close the AMS Machine Studio and disconnect the connection to the communication card.

After these steps, the Temperature Process Card is ready for operation.

Enable system programming with A6500-CP communication card

Set the key-switch of the A6500-CP Com Card Pro to unlock to enable programming of the AMS 6500 ATG system. See [Figure 6-1](#) for the position of key-switch and **Prog. LED** on the front plate.

The enabled system programming is indicated by:

- A switched on **Prog. LED**
- An unlock symbol in the device tree behind the related AMS 6500 ATG system
- A status information in the online view


- Modbus register and OPC UA data point

Table 6-1: Status indication through Modbus and OPC UA

Function	Modbus register	OPC UA data point
Key switch state	KeySwitchState	KeySwitchState
System program state	SystemProgramState	SystemProgramState

The system program status shows whether sending of configurations to the AMS 6500 ATG system or firmware updates are allowed or not.

Figure 6-1: Key-switch in unlocked position



Enable system programming with redundant A6500-CP communication cards

Set the key-switch of both A6500-CP Com Cards Pro to unlock to enable programming of the AMS 6500 ATG system. [Table 6-2](#) explains the behavior of the communication cards with key-switches in different positions.

Table 6-2: Key-switch position to enable system programming in a redundant system

A6500-CP left slot		A6500-CP right slot		System programming
Key-switch	Prog. LED	Key-switch	Prog. LED	
Locked	Off	Locked	Off	Disabled
Unlocked	Off	Locked	Off	Disabled
Locked	Off	Unlocked	Off	Disabled

Table 6-2: Key-switch position to enable system programming in a redundant system (continued)

A6500-CP left slot		A6500-CP right slot		System programming
Key-switch	Prog. LED	Key-switch	Prog. LED	
Unlocked	On	Unlocked	On	Enabled

See [Figure 6-2](#) for the position of key-switch and **Prog. LED** on the front plate.

An enabled system programming is indicated by:


- A switched on **Prog. LED**
- An unlock symbol in the device tree behind the related AMS 6500 ATG system
- A status information in the online view
- Modbus register and OPC UA data point

Table 6-3: Status indication through Modbus and OPC UA

Function	Modbus register	OPC UA data point
Key switch state	KeySwitchState	KeySwitchState
System program state	SystemProgramState	SystemProgramState

The system program status shows whether sending of configurations to the AMS 6500 ATG system or firmware updates are allowed or not.

Figure 6-2: Key-switch in unlocked position




- Program LED (Prog. LED)
- Key-switch in unlocked position
- Indication in AMS Machine Studio
- Online view of the A6500-CP cards

6.2 Start of an offline card configuration

Procedure

1. Select **Workspace** in the left part of the **Home** view then click **Item** (see [Figure 6-3](#)).


Figure 6-3: Start new device configuration



A. *Workspace*
B. *Button Item*

2. Select **Temp/Process Card (A6500-TP)** from the device list (see [Figure 6-4](#)).


Figure 6-4: Device selection



The Temperature Process Card is added to the list below **Workspace**.

3. Select **A6500-TP** from the device list and click **Configure**.

Figure 6-5: Open editor



- A. New Temperature Process Card
- B. Button **Configure** to open the configuration editor

The New configuration dialog opens.

4. Click **Create configuration** to open the configuration editor.
See [Configuration editor and parameters](#) for parameter description and settings.


6.3

Start of an online card configuration

Procedure

1. Select the A6500-TP card to be configured from the **Network** list in the left part of the **Home** view, then click **Configure** (see [Figure 6-6](#)).

Figure 6-6: Select a Temperature Process Card for online configuration



- A. Selected A6500-TP card
- B. Button **Configure** for opening the configuration editor

The **New configuration** dialog opens if an unconfigured card has been selected, otherwise the configuration editor opens (continue with [Step 3](#)).

2. Click **Create configuration** to open the configuration editor.
3. Check the configuration and modify it in accordance to the measuring task. See [Configuration editor and parameters](#) for parameter description and settings.

6.4

Configuration of an already existing card


Procedure

1. Select the card to be reconfigured from the **Network** list.
2. Click **Configure** to open the configuration window.
3. Make the changes to the configuration.
4. Send the configuration to the card (see [Send a configuration](#)).

6.5

Configuration editor and parameters

[Figure 6-7](#) shows an overview of the general configuration editor.

Figure 6-7: Configuration editor

- A. Ribbon command bar
- B. Card name and position within the rack (only visible at connected racks, for example: R1 = Rack 1; S08 = Slot 8)
- C. List of configuration pages
- D. Configuration page

6.5.1 Ribbon command bar

The ribbon command bar of Configuration shows the icons for the file handling:

New configuration

Figure 6-8: Button "New configuration"

Click **New configuration** to create a new configuration with default parameters.

Send & close

Figure 6-9: Button "Send & close"

Click **Send & close** to send the configuration to the Temperature Process Card. The configuration editor automatically closes after the sending process. This command requires an online connection to the card. See [Send a configuration](#).

⚠ CAUTION

The machine protection function of the card is disabled during sending of configurations with major changes because of a reboot of the A6500-TP Card.

Reload**Figure 6-10: Button "Reload"**

Click **Reload** to reload the configuration from the Temperature Process Card to the configuration editor.

Delete configuration**⚠ CAUTION**

The configuration on the card will be deleted.

Figure 6-11: Button "Delete configuration"

Click **Delete configuration** to delete the configuration of the connected Temperature Process Card. The OK LED is flashing after the successful deletion of the configuration. A card without configuration is marked with the "No configuration" sign in the Online View (see [Figure 6-12](#)).

Figure 6-12: No configuration sign**Compare****Figure 6-13: Button "Compare"**


Click **Compare** to open further compare functions.

Figure 6-14: Compare functions




to other card Click to other card to open a dialog for selecting a card from the device three with a configuration to be compared with the currently opened configuration. Selectable cards are in bold.

Figure 6-15: Selection dialog – other card



1. Expand the listed AMS 6500 ATG systems and racks to see the cards available for selection.
2. Click a card to select it. A selected card is highlighted blue.
3. Click OK to open the report with the result of the comparison. The report can be printed or exported (see [Report](#) for details).

to history/drafts Click to history/drafts to open a dialog for selecting a draft or historic configuration of the card to be compared with the currently opened configuration.

Figure 6-16: Select dialog – history/drafts

1. Click a configuration to select it. A selected configuration is highlighted blue. See [Show History/Drafts](#) for an explanation of the different types (Draft Config, Running Config, and Running Config (historic)).
2. Click **OK** to open the report with the result of the comparison. The report can be printed or exported (see [Report](#) for details).

Report

Figure 6-17: Button "Report"


Click **Report** to open the report viewer. This report shows all configured parameters and some additional information as, for example, serial number and user information. This report can be printed or exported to different file formats.

The logos in the header of the report can be changed:

1. Close the configuration editor.


2. Click tab **File** and then **Settings**.
The window **Settings** opens (see [Figure 6-18](#))
3. Click the buttons with the dotted line within the **Report settings** area to browse for logos.
Logos with file format "png" or "jpg" can be selected.
4. Click **OK** to confirm your settings.
The window closes.
5. Open the configuration editor and go back to the report.
Now the report contains the selected logos.

Figure 6-18: General settings




Show History/Drafts

Figure 6-19: Button "Show History/Drafts"



Click **Show History/Drafts** to open the History (see [Figure 6-20](#)).

Figure 6-20: History



The right part of Figure 6-20 shows the configuration history. The individual files are marked with date and time and type:

Draft Config	A saved preliminary configuration file which has not yet send onto the card.
Running Config	This configuration file is running on the connected card.
Running Config (historic)	An old configuration file which was running in the past.

The editor area is grayed out. You can see the parameters of the historic files but you can not change them. Parameters can be only changed in the editor. Copying a historic configuration to the editor:

- Select a draft or historic file from the right list of the window by a left mouse click. The parameter of the selected file are displayed in the grayed out editor area.
- Click **Revert** (see Figure 6-21). The selected file is copied to the editor and the history window closes. Click **Show History/Drafts** again, if you want to leave the history without any file copying.


Figure 6-21: Button "Revert"



Revert

Close configuration

Figure 6-22: Button "Close configuration"



Click **Close configuration** to leave the editor. Changes are automatically saved as a draft configuration. A saved draft can be opened in the history view.

6.5.2 Basic

Basic information about the system, the machine, where the system is installed, and the location where the system rack with this card is installed is managed using this menu. The menu also indicates the name of the user who made the last changes of configurations along with date and time of the last changes. See [Figure 6-23](#).

Figure 6-23: Basic

A6500-TP (R1 S08)	
	Configuration - Draft
Basic	
Sensor input 1	
Sensor input 2	
Sensor input 3	
Sensor input 4	
Cold junction compensation	
Digital inputs	
Calculation	
Current output 1	
Current output 2	
Current output 3	
Current output 4	
Digital outputs	
Basic	
Card name:	A6500-TP
Machine:	
Area:	
Plant:	
User:	User Name
Date (last change):	5/10/2023 11:11:34 AM
Configuration version:	

Card name	Designation for card type.
Machine	Designation for the machine where this system is installed.
Area	Area in plant or factory where the system is installed.
Plant	Designation for the location where the system is implemented.
User	<p>The name of the user who made the last configuration is displayed.</p> <p>The stored user name depends on the communication card used in the AMS 6500 ATG system.</p> <ul style="list-style-type: none">• Online configuration with A6500-CP: The configuration stored on the A6500-TP card contains the name of the user who was logged into the AMS 6500 ATG system while the configuration was created. Locally stored configurations of devices below NETWROK do not contain a user name.

- Online configuration with A6500-CC: The configuration stored on the A6500-TP card contains the user name of the user who was logged into the operation system while the configuration was created.
- Offline configuration: Locally stored configuration files, configuration files below **WORKSPACE** and **LIBRARY** contain the user name of the user who was logged into the operation system while the configuration was created.

It is not possible to change the content of this field.

Date (last change)	Date and time of the last changes to this configuration. Time and date of the configuration PC is used. It is not possible to change the content of this field.
Configuration version	The version of AMS Machine Studio used to configure the card is displayed.

6.5.3 Sensor input

The sensor input configuration contains a list with two parameter subgroups "Sensor A" and "Sensor B" to define measuring function, sensor type, measuring range, and sensor offset. See [Figure 6-24](#).

Two subgroups A and B are only possible for thermocouple measurement and for a thermocouple in combination with an RTD.

There are no subgroups if input type **Process value** or **RTD's** is selected.

Figure 6-24: Sensor input

A6500-TP (R1 S08)		Configuration 5/15/2023 9:22:29 AM - Draft
Basic		
Sensor input 1		Sensor input 1
Sensor input 2		Sensor input 2
Sensor input 3		Sensor input 3
Sensor input 4		Sensor input 4
Cold junction compensation		
Digital inputs		
Calculation		
Current output 1		
Current output 2		
Current output 3		
Current output 4		
Digital outputs		
Point Id:		
Input type:		
Sensor A:		
Lower analysis range A [°C]:		
Upper analysis range A [°C]:		
Temperature offset A [°C]:		
Sensor B:		
Lower analysis range B [°C]:		
Upper analysis range B [°C]:		
Temperature offset B [°C]:		

Point ID Enter here the description for the measuring point at the machine.

Input type Select a measuring function from the **Input type** menu.

- **Thermocouple**

Temperature measurement with thermocouple.

- **Thermocouple and RTD2**

Temperature measurement with thermocouple and measurement of cold junction temperature with RTD.

- **RTD**
Temperature measurement with RTD.
- **Process value**
Measurement of process values 0 - 1 V, 0 - 10 V, or 0 - 20 mA / 4 - 20 mA.
- **No function (Off)**
No measuring function for this channel.

⚠ CAUTION


Because of the high sensitivity of the sensor inputs, signals can be detected even at open inputs. To avoid an unintentional behavior of the card, deactivate unused input channels – select **No function (Off)**.

Temperature measurement with thermocouples

Select measuring function **Thermocouples** by clicking on this line in field **Input type**.

Click on the selection button  right of line **Sensor A** to open submenu **Select component** (see [Figure 6-25](#)).

Figure 6-25: Selection menu thermocouple type



Click on the desired type description on the left side to select the type of thermocouple for your application. For information, the fields on the right side show the possible temperature range in fields **Min range** and **Max range**. The parameter fields on the right side of this menu are only for information purposes, these parameters cannot be changed.

- **Off**
No sensor selected
- **Thermocouple type E**
NiCr - CuNi: Nickel Chromium (Chromel) - Copper Nickel (Constantan)
- **Thermocouple type J**
Fe - CuNi: Iron - Copper-Nickel (Constantan)

- **Thermocouple type K**

NiCr - NiAl: Nickel Chromium (Chromel) - Nickel Aluminum

- **Thermocouple type T**

Cu - CuNi: Copper - Copper-Nickel (Constantan)

- **Thermocouple type N**

NiCrSi - NiSi: Nickel Chromium Silicon (Nicrosil) - Nickel Silicon (Nisil)

Click **OK** to confirm the selection. The program returns to menu **Configuration**.

Line **Sensor A** (sensor connected to sub channel A) of this menu shows the selected sensor type and in the fields below the parameters for measuring range and temperature offset:

Lower analysis range A Enter the lower limit value for the analysis range.

[°C]

Upper analysis range A Enter the upper limit value for the analysis range.

[°C]

Temperature offset A Use this field if the temperature can not be measured directly

and the temperature difference between the actual measurement point and the installation place of the temperature sensor is known. Enter the temperature difference (offset). Permissible range -200 to +300°C.

When entering parameters into these fields, only digits and minus-signs are allowed. Figures without signs are assumed to be positive (see [Figure 6-24](#)).

In the same way you can enter parameters for the sensor connected to subchannel B.

Temperature measurement with thermocouple and RTD2

For this measuring function subchannel A is programmed for a thermocouple and subchannel B for a 2-pole RTD measurement function.

Select measuring function **Thermocouples and RTD2** by clicking on this line in field. Click on the selection button  right of line **Sensor A** to open submenu **Select component**. See [Figure 6-25](#).

Click on the desired type description on the left side to select the type of thermocouple for your application. For information, the fields on the right side show the possible temperature range in fields **Min range** and **Max range**. The parameter fields on the right side of this menu are only for information purposes, these parameters cannot be changed.

Click **OK** to confirm the selection. The program returns to menu **Configuration**.

Line **Sensor A** shows the selected sensor type and in the fields below the parameters for measuring range and temperature offset.

Lower analysis range A Enter the lower limit value for the analysis range.

[°C]


Upper analysis range A Enter the upper limit value for the analysis range.

[°C]

**Temperature offset A
[°C]**

Use this field if the temperature can not be measured directly and the temperature difference between the actual measurement point and the installation place of the temperature sensor is known. Enter the temperature difference (offset). Permissible shift range -200 to +300°C.

To configure the measurement for the cold junction temperature click on the selection button  right of line **Sensor B** to open submenu **Select component** (see [Figure 6-26](#)).

Figure 6-26: Selection menu RTD2

This menu permits selection of the RTD type to measure the temperature at the cold junction point.

Choice between the following measuring elements:

- **Off**
No sensor selected
- **Pt100 (2)**
Platin temperature sensor, basic resistance 100 Ω
- **Ni100 (2)**
Nickel temperature sensor, basic resistance 100 Ω
- **Ni120 (2)**
Nickel temperature sensor, basic resistance 120 Ω

Note

Measurements of the cold junction temperature for thermocouple measurements, can be made with any RTD, connected to this card. The assignment of the cold junction measuring point to the RTD is made in menu **Cold junction compensation**.

Click on the appropriate sensor type then click **OK** to confirm the choice.

The program returns to application window **Configuration**. The selected sensor, in this example, is a Platin temperature sensor Pt100. It is shown in the parameter fields just below the thermocouple parameters. Measuring range for this sensor is -200 to +850°C. If necessary, the parameter field **Temperature offset B** permits correction of the cold junction temperature by entering an offset value.

Lower analysis range B [°C] Enter the lower limit value for the analysis range.


Upper analysis range B [°C] Enter the upper limit value for the analysis range.

Temperature offset B [°C] Use this field if the temperature can not be measured directly and the temperature difference between the actual measurement point and the installation place of the temperature sensor is known. Enter the temperature difference (offset). Permissible shift range -200 to +300°C.

Temperature measurement with RTDs

This measuring function can only be selected for subchannel B. Select measuring function RTD's by clicking on this line in field **Input type**. Click on the selection button  right of line **Sensor** to open submenu **Select component**. See [Figure 6-27](#).

[Figure 6-27: Selection menu RTD sensors](#)



Choice between the following measuring elements:

- **Off**
No sensor selected
- **Pt100 (2)**
Platin temperature sensor, 100 Ω / 0°C, 2-wire connection, -200 to 850°C
- **Pt100 (3)**
Platin temperature sensor, 100 Ω / 0°C, 3-wire connection, -200 to 850°C
- **Pt100 (4)**
Platin temperature sensor, 100 Ω / 0°C, 4-wire connection, -200 to 850°C
- **Ni100 (2)**

Nickel temperature sensor, 100 Ω / 0°C, 2-wire connection, -60 to 180°C

- **Ni100 (3)**

Nickel temperature sensor, 100 Ω / 0°C, 3-wire connection, -60 to 180°C

- **Ni100 (4)**

Nickel temperature sensor, 100 Ω / 0°C, 4-wire connection, -60 to 180°C

- **Ni120 (2)**

Nickel temperature sensor, 120 Ω / 0°C, 2-wire connection, -80 to 260°C

- **Ni120 (3)**

Nickel temperature sensor, 120 Ω / 0°C, 3-wire connection, -80 to 260°C

- **Ni120 (4)**

Nickel temperature sensor, 120 Ω / 0°C, 4-wire connection, -80 to 260°C

- **Cu10 (4)**

Copper temperature sensor, 10 Ω / 25°C, 4-wire connection, -80 to 260°C


In this example the temperature measurement with Pt100 in 4-wire connection and a measuring range of -200 to 850°C has been selected. The parameters in the right part of the menu are for information only and cannot be modified in this menu. Changes of the measuring range or temperature are only possible in application window **Configuration**.

Click **OK** to confirm the selection, the program returns to window **Configuration**. If necessary, the measuring range may be modified in lines **Lower analysis range [°C]** and **Upper analysis range [°C]**, the last line in the table permits correction of the measuring value by entering a temperature offset.

Measurement of process values

Select measuring function **Process values** by clicking on this line in field **Input type**. Click on the selection button  right of line **Sensor** to open submenu **Select component** (see Figure 6-28).

Figure 6-28: Selection menu process values



Menu **Sensor component** shows a list of options for this function:

- **Off**
No function.

- **0 - 1 V**
Measurement of dc-voltage, maximum value 1 V.
- **0 - 10 V**
Measurement of dc-voltage, maximum value 10 V.
- **0 - 20 mA**
Dead-zero dc current measurement, input impedance 200 Ω .
- **4 - 20 mA**
Life-zero dc current measurement, input impedance 200 Ω .

Click on the required range then click **OK** to confirm the selection. [Figure 6-29](#) shows the input page for configuration of process input signals.

Figure 6-29: Application window, selection process value 10 V

A6500-TP (R1 S08)	Configuration 5/15/2023 9:22:29 AM - Draft
Basic Sensor input 1 Sensor input 2 Sensor input 3 Sensor input 4 Cold junction compensation Digital inputs Calculation Current output 1 Current output 2 Current output 3 Current output 4 Digital outputs	Sensor input 1 Point Id: Input type: Sensor: Lower analysis range [V]: Upper analysis range [V]: Lower process value [mm]: Upper process value [mm]: Unit: Zero point: Gain factor:
	Process value 0 - 10 V 0 10 0 10 mm 0 1

Point ID	Enter the description for the measuring point at the machine.
Input type	By clicking on the pull-down menu in the right part of this line, a list of measuring functions appears. Click a measuring function to select it.
Sensor	Click on the selection button  to open the dialog for the selection of the measuring range.
Lower analysis range [X]	(X = [V] or [mA]) Enter the lower limit value for the analysis range.
Upper analysis range [X]	(X = [V] or [mA]) Enter the upper limit value for the analysis range.
Lower process value [unit]	Enter the lower limit value for scaling the process value. The entered value must be smaller than the upper process value.
Upper process value [unit]	Enter the upper limit value for scaling the process value. The entered value must be greater than the lower process value.
Unit	Click the arrow to the right in this line to open a drop-down menu with units. Click a unit to select it.
Zero point	Enter a value to shift the zero point of the process value range.
Gain factor	Enter a value to change the slope of the scaled output characteristic.

Parameter **Zero point** serves the shifting of the zero point, for example, if the zero indication of the protection card is different to the zero point of the signal source.

Parameter **Gain factor** serves the correction of the indication by slightly varying the slope of the characteristic in the range 0.9 ... 1.1.


According to your application, configure **Sensor input 2** to **Sensor input 4** in the same way as described above for **Sensor input 1**.

6.5.4

Cold junction compensation

The cold junction point is the point where the wires of the thermocouple come into contact with other metals for example, copper wires. The temperature at this cold junction point has to be determined for compensation to calculate the correct temperature of the hot junction point (see [Figure 6-30](#)).

Figure 6-30: Cold junction compensation



The **Cold junction compensation** menu shows two input options: **Fix value** or **Sensor input x - Temperature**.

Parameter cold junction compensation is necessary for thermocouple measurements. The program offers two options for this parameter:

- **Fix value**

The temperature at the point where compensating lines are connected to copper lines must be entered. In order to achieve a correct measurement, the temperature at this point has to be very stable and constant. Any change of the temperature will directly influence the measuring result.

- **Sensor input x - Temperature** (x = channel number 1 to 4)

Measuring channel equipped with an RTD. This sensor has to be placed as close as possible to the connection point of compensating line and copper cable.


When using option **Fix value**, enter the temperature in the menu shown in the picture above.

When using option **Sensor input x - Temperature**, open the drop down menu by clicking the arrow to the right in this line. The program will show all channels with measuring function RTD. Select the sensor that is used for the measurement of the cold junction

temperature and confirm your choice with a click on the according line. For example, see **Sensor input 2 - Temperature** shown in the example below.

With this choice, the RTD-sensor connected to channel 2 of this card is now defined for the measurement of the cold junction temperature and applies for all thermocouple channels of this card (see [Figure 6-31](#)).


Figure 6-31: Cold junction compensation – selection example



Cold junction compensation, option Fix value

Place the connection point of the thermocouple in a closed box with a constant temperature and enter this temperature in the configuration software - line **Fix value** (see [Figure 6-32](#)).

Figure 6-32: Cold junction compensation, constant temperature



- A. Hot junction point
- B. Cold junction point
- C. Thermocouple
- D. Metal 1
- E. Metal 2
- F. Constant temperature
- G. Copper wires

⚠ CAUTION


Any change of the temperature at the cold junction point will directly influence the thermocouple measuring result.

Cold junction compensation, option Sensor input x - Temperature

The more precise way is to measure the temperature at the point where the wires of the thermopair come into contact with copper wires (see [Figure 6-33](#)). This is usually the

signal input of a measuring device or the input of a cold junction box. When installing A6500-TP Temperature Process Cards, the RTD for measuring the cold junction temperature may be connected to any input channel and applies for all thermocouple channels of this card.

Figure 6-33: Cold junction compensation, measured value with RTD sensor



- A. Hot junction point
- B. Cold junction point
- C. Thermocouple
- D. Metal 1
- E. Metal 2
- F. Pt 100
- G. Copper wires

Click on the drop down button to the right of line **Source** and select option **Sensor input X - Temperature**.

With this selection, the terminal contacts of input X must be installed with an RTD sensor for the measurement of the cold junction temperature. The sensor may be installed in 2-pole, 3-pole or 4-pole connecting mode.

More detailed information on the installation of the temperature resistor are shown in the A6500-xR System Racks operating manual (MHM-97877). The configuration of this sensor is described in [Temperature measurement with thermocouple and RTD2](#).

6.5.5 Digital inputs

The A6500-TP Temperature Process Card has two digital inputs to control several functions.

To configure the digital inputs, assign a digital input to the function to be controlled, see [Figure 6-34](#).

To control the four channel bypasses through the Modbus or OPC UA interface, select **Modbus/OPC UA** for the channel to be bypassed. The typical reaction time for a command through the Modbus or OPC UA interface is approximately one second. The reaction time is the time between sending the command and the recognition of the command by the A6500-TP Card. The reaction time might be higher at a high input load.

Figure 6-34: Digital inputs

A6500-TP (R1 S08)		Configuration 12/16/2021 11:39:07 AM - Draft			
Digital inputs					
Function	DI 1	DI 2	Modbus/OPC UA	Off	
Identify	<input type="radio"/>	<input type="radio"/>		<input checked="" type="radio"/>	
Bypass CH 1	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	
Bypass CH 2	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	
Bypass CH 3	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	
Bypass CH 4	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	
Reset min/max values	<input type="radio"/>	<input type="radio"/>		<input checked="" type="radio"/>	
Reset latch DO 1	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 2	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 3	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 4	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 5	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 6	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 7	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 8	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 9	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 10	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 11	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 12	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 13	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 14	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 15	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Reset latch DO 16	<input checked="" type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Event trigger	<input type="checkbox"/>	<input checked="" type="checkbox"/>		<input type="checkbox"/>	

Digital input 1 **DI1** and digital input 2 **DI2** can be assigned to the functions shown in column **Function**. Activate the functions by clicking the radio button in the corresponding field, a selected function is indicated by a filled circle.

Identify	When an active low signal pulse is sent to a digital input, the LEDs Alarm 1 , Alarm 2 , and OK of the addressed protection card start flashing in circular sequence for about 15 seconds for identification purposes. With a continuous signal at the digital input, the LEDs on the card front will be flashing continuously. The Identify function is useful for the recognition of individual cards in cabinets with several installed racks. Alternatively, start this function by clicking on Identify in the Commands section of the ribbon bar .
Bypass CH 1 to Bypass CH 4	Disable the input channels channel by channel. An input channel with activated bypass is disabled and all functions assigned to this channel are inactive. See Bypass .
	⚠ DANGER
	Bypassed input channels are not part of the machine protection while Bypass is activated.
Reset min/max values	With a digital pulse at one of the digital inputs DI1 or DI2, the indicated minimum and maximum values in menus Overview and Details will be reset.
Reset latch Out x	(x = alarm output 1 to 16; 1 to 6 physical outputs, 7 to 16 only software outputs (Modbus and OPC UA)) Digital outputs of the A6500-TP Temperature Process Card may be assigned to any channel and programmed for different alarm monitoring functions with or without latching. If you have configured a digital output channel with an alarm function with latching, and if this output has indicated an alarm and remains switched on even when the alarm condition is no longer present, the output can be reset with a digital input and function Reset latch Out x . Alternatively, this function can also be carried out through AMS Machine Studio with a click on command Reset latch x in application window Home of the respective protection card.
Event trigger	Digital inputs can be used to trigger data capturing. Check the box to activate triggering for the associated digital input. Download the configuration to the A6500-TP card to use the trigger for the configuration of collection tasks (see operating manual AMS Machine Studio – General Functions for details).

6.5.6

Calculation

Configure one or two calculations. The result can be selected as a data source for a digital output (see [Digital outputs](#)) or assigned to a current output (see [Current outputs](#)).

Note

All input channels used for the calculation must have channel status **OK**, otherwise the calculation cannot be executed.

Figure 6-35: Calculation

A6500-TP (R1 S08)		Configuration 9/23/2020 11:25:11 AM - Running	
Basic Sensor input 1 Sensor input 2 Sensor input 3 Sensor input 4 Cold junction compensatio Digital inputs Calculation Current output 1 Current output 2 Current output 3 Current output 4 Digital outputs	Calculation 1 Mode : <input type="button" value="Average"/> <input checked="" type="checkbox"/> Sensor input 1 - Temperature [°C] <input checked="" type="checkbox"/> Sensor input 2 - Temperature [°C] <input checked="" type="checkbox"/> Sensor input 3 - Temperature [°C] Average channels : Range min [°C]: 0 Range max [°C]: 100 Formula [°C]: $(1B + 2B + 3B) / 3$		
	Calculation 2 Mode : <input type="button" value="Differential"/> <input checked="" type="checkbox"/> Sensor input 1 - Temperature [°C] <input checked="" type="checkbox"/> Sensor input 2 - Temperature [°C] <input type="checkbox"/> Sensor input 3 - Temperature [°C] Differential channel : <input type="button" value="Sensor input 3 - Temperature [°C]"/> Range min [°C]: -200 Range max [°C]: 100 Formula [°C]: $3B - (1B + 2B) / 2$		

Mode	Select a calculation mode.
None	Calculation is disabled.
Average	Select Average to calculate the arithmetic mean of selectable input channel values.
Differential	Select Differential to calculate the difference of an input channel value and the arithmetic mean value (average).
Max deviation	Select Max deviation to calculate the deviation between the input channel value and the greatest difference to the arithmetic mean value (average). In this mode, the input channel value with the greatest difference to the average value and the same unit is automatically selected for the calculation.
Average channels	All configured input channels available for the calculation are listed. Check the box to select an input channel. Ensure that the values of the selected channels have the same unit.
Differential channel	Available if Differential is selected for Mode . Select an input channel to be used for the differential calculation. Ensure that the value of the selected channel has the same unit as the input channels used for the average calculation.
Range min	Enter a value to define the beginning of the range of the calculated value. An assigned current output is scaled on this range.
Range max	Enter a value to define the end of the range of the calculated value.

Formula The formula used for the calculation is displayed.

6.5.7 Current outputs

The A6500-TP Temperature Process Card is equipped with four current outputs. The outputs can be configured for dead zero, 0 to 20 mA, or life zero range, 4 to 20 mA. For the configuration, click on one of the lines **Current output 1 to 4**. The window shown in [Figure 6-36](#) appears.

Figure 6-36: Current output

A6500-TP (R1 S08) Configuration 4/27/2022 1:37:22 PM - Draft

Current output 1

Measuring source: Sensor input 1

Mode: 4 - 20 mA

Optional parameter (active)

Use default setting Use custom setting Reset to default

Current suppression:

Current delay [s]: 0

Range min. [°C]: -200

Range max. [°C]: 850

Break points:

Break point 1 value [%]: 25

Break point 1 scale [%]: 25

Break point 2 value [%]: 75

Break point 2 scale [%]: 75

Measuring source Select the sensor input channel to be output via this current output. The option **No measurement** disables the corresponding current output.

Note

You can select only those channels as output source that have been activated before. Sensor inputs with deactivated measuring function **Off** do not appear in this menu.

Mode Select the required output current range:

- 0 to 20 mA
- 4 to 20 mA
Activation of the current suppression function is possible.
- 20 to 4 mA
Activation of the current suppression function is possible.
- 20 to 0 mA


By using the life zero range 4 to 20 mA, externally connected devices can be able to detect wire breaks or system failures. A drop of the output current below 4 mA indicates a malfunction or wire break.

Optional parameter – current output

Click the down arrow in front of **Optional parameter** to open additional parameters for the current output.

Use default setting	Select this option to use the default settings.
Use custom setting	Select this option to individually adjust the settings to the measuring task. To reset the settings to the default values, click Reset to default behind this option.
Current suppression	Available for ranges 4 to 20 mA and 20 to 4 mA. Check the box to activate the current suppression. The function is active if the box is marked. In case of a fault, the current is set to 0 mA.
Current delay [s]	In order to achieve stable output currents at unstable or disturbed measuring values, enter a time in a range of 1 to 20 seconds (0 seconds = no settling) to settle the output current. The time causes a slow change in the current at fast changes of the measurement value. With a time of 20 seconds and a sudden change of the measurement value from 100% to 0% it will take approximately 20 seconds until the current has dropped by 63% (left diagram in Figure 6-37). The right diagram in Figure 6-37 shows the change curve for a sudden change of the measurement value from 0 to 100%.


Figure 6-37: Diagram current output settling



Range min. and Range max.	Use these parameters for scaling the current output on a reduced measuring range. Enter the range minimum and the range maximum of the needed measuring range.
Break points	Use this function to divide the linear current output curve into an output curve with up to three linear parts with different gradients. Check the box to activate the break point function. After activation, four parameters for defining the break points appear: <ul style="list-style-type: none"> • Break point 1 value [%] • Break point 1 scale [%] • Break point 2 value [%] • Break point 2 scale [%]

The break points are defined in percent of the configured output range and measuring range. Figure 6-38 shows a break point example with a first break point at value 1 = 25% and scale 1 = 57% and the second break point at value 2 = scale 2 = 75%

Figure 6-38: Example diagram break point



6.5.8 Digital outputs

The A6500-TP Temperature Process Card is equipped with six hardware digital outputs and ten software digital outputs for supervision of measuring results and indication of alarm states. All outputs (DO 1 to DO 16) are available through Modbus and OPC UA communication. The six outputs DO1 to DO6 are also assigned to the six hardware outputs of the card.

Figure 6-39: Digital outputs

A6500-TP (R1 S08)		Digital outputs								
		Output	Data source	Function	Limit 1	Limit 2	Hysteresis	Delay	Circuit mode	Type
Basic Sensor input 1 Sensor input 2 Sensor input 3 Sensor input 4 Cold junction compensation Digital inputs Calculation Current output 1 Current output 2 Current output 3 Current output 4	DO 1	Sensor input 1 - Temperature	<input checked="" type="checkbox"/>	\geq Limit	-	350	5	5	Normally open	<input checked="" type="checkbox"/>
	DO 2	Sensor input 2 - Temperature	<input checked="" type="checkbox"/>	\geq Limit	-	350	5	5	Normally open	<input checked="" type="checkbox"/>
	DO 3	Sensor input 3 A - Temperature	<input checked="" type="checkbox"/>	\geq Limit	-	300	1	5	Normally open	<input checked="" type="checkbox"/>
	DO 4	Calculation 1 - Max deviation 1	<input checked="" type="checkbox"/>	\geq Limit	-	15	0	0	Normally open	<input checked="" type="checkbox"/>
	DO 5	Channel OK - Combined	<input checked="" type="checkbox"/>	Normal	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
	DO 6	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
	DO 7	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
	DO 8	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
	DO 9	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
	DO 10	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
Digital outputs	DO 11	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
	DO 12	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
	DO 13	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
	DO 14	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
	DO 15	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
	DO 16	No measurement	<input checked="" type="checkbox"/>	Off	-	-	-	-	Normally open	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Limit suppression										
Select the sensor inputs to be combined for the Channel OK: Output 1A 1B 2A 2B 3A 3B 4A 4B Bypass affects Channel OK DO 5 <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/>										

Configure a hardware or software output.

1. Assign a data source to a hardware or software output.
2. Select a function for the measuring result supervision.
3. Enter limits depending on the select function.
4. If needed, enter a hysteresis.
5. If needed, add a delay.
6. If a hardware output is used, select a circuit mode.

Repeat these steps for all data sources to be supervised.

Column description of the **Digital outputs** table:

Output	Number of the digital output. DO 1 to DO 6 are hardware outputs. DO 7 to DO 16 are software outputs.										
Data source	<p>Available data sources depend on the card configuration. A data source could be a configured sensor input, result of a calculation, or the Channel OK supervision.</p> <p>When data source Channel OK - Combined is selected, a sensor inputs selection field appears below the Digital outputs table. Each configured subchannel has a check box assigned.</p> <p>By selecting individual status outputs with a checkmark, these outputs will be AND operated to switch the according digital output. The output will be switched when all selected subchannels show the OK state. If one of these outputs fails, the assigned digital output will be switched off. The data source Channel OK - Combined can be assigned to hardware outputs.</p>										
Function	<p>Available functions for a data source. Different alarm functions are not available when data source Channel OK - Combined is selected. The function is set to Normal as the result of the Channel OK supervision switches directly the digital output, without any limit supervision.</p> <table border="0"> <tr> <td>Off</td><td>No alarm function activated.</td></tr> <tr> <td>>= Limit</td><td>The effective direction of this alarm is increasing, the alarm is triggered if the measuring value exceeds the defined limit. If the value falls below the limit again (limit value minus hysteresis), the alarm is reset.</td></tr> <tr> <td>>=Limit (Latch)</td><td>The effective direction of this alarm is increasing, the alarm is triggered if the measuring value exceeds the defined limit. If the value falls below the limit again (limit value minus hysteresis), the alarm is only reset if a reset-latch command is given (see Digital inputs, Reset latch Out x).</td></tr> <tr> <td><= Limit</td><td>The effective direction of this alarm is decreasing, the alarm is triggered if the measuring value falls below the defined limit. If the value exceeds the limit again (limit value plus hysteresis), the alarm is reset.</td></tr> <tr> <td><=Limit (Latch)</td><td>The effective direction of this alarm is decreasing, the alarm is triggered if the measuring value falls below the defined limit. If the value exceeds the limit again (limit value plus</td></tr> </table>	Off	No alarm function activated.	>= Limit	The effective direction of this alarm is increasing, the alarm is triggered if the measuring value exceeds the defined limit. If the value falls below the limit again (limit value minus hysteresis), the alarm is reset.	>=Limit (Latch)	The effective direction of this alarm is increasing, the alarm is triggered if the measuring value exceeds the defined limit. If the value falls below the limit again (limit value minus hysteresis), the alarm is only reset if a reset-latch command is given (see Digital inputs, Reset latch Out x).	<= Limit	The effective direction of this alarm is decreasing, the alarm is triggered if the measuring value falls below the defined limit. If the value exceeds the limit again (limit value plus hysteresis), the alarm is reset.	<=Limit (Latch)	The effective direction of this alarm is decreasing, the alarm is triggered if the measuring value falls below the defined limit. If the value exceeds the limit again (limit value plus
Off	No alarm function activated.										
>= Limit	The effective direction of this alarm is increasing, the alarm is triggered if the measuring value exceeds the defined limit. If the value falls below the limit again (limit value minus hysteresis), the alarm is reset.										
>=Limit (Latch)	The effective direction of this alarm is increasing, the alarm is triggered if the measuring value exceeds the defined limit. If the value falls below the limit again (limit value minus hysteresis), the alarm is only reset if a reset-latch command is given (see Digital inputs, Reset latch Out x).										
<= Limit	The effective direction of this alarm is decreasing, the alarm is triggered if the measuring value falls below the defined limit. If the value exceeds the limit again (limit value plus hysteresis), the alarm is reset.										
<=Limit (Latch)	The effective direction of this alarm is decreasing, the alarm is triggered if the measuring value falls below the defined limit. If the value exceeds the limit again (limit value plus										

hysteresis), the alarm is only reset if a reset-latch command is given (see [Digital inputs](#), [Reset latch Out x](#)).

Window Use the limit values **Limit 1** and **Limit 2** to define a limit window. The function output is set if the measured signal level exceeds or falls below one of the two limit values (see [Figure 6-40](#)).


The function output remains in its initial state as long as the measuring value remains within the limits.

Window (Latch) Use the limit values **Limit 1** and **Limit 2** to define a limit window. The function output is set if the measured signal level exceeds or falls below one of the two limit values.

The function output is in its initial state as long as the measuring value remains within the limits.

If the measuring value exceeds a limit and then returns within the limits (limit value 1 plus hysteresis and limit value 2 minus hysteresis), the alarm is only reset if a reset-latch command is given (see [Digital inputs](#), [Reset latch Out x](#)).

Figure 6-40: Alarm function "Window"



- A. Measuring value
- B. Limit 2
- C. Hysteresis
- D. Limit 1
- E. No alarm
- F. Alarm
- G. Time


Limit 1 Limit value for defining an alarm window. This input field appears when the alarm function **Window** or **Window (Latch)** has been selected.

Parameter **Limit 1** must always be smaller than **Limit 2**.

Limit 2 Limit value for alarm supervision. This limit value applies to all alarm supervision functions.

Hysteresis Definition of the hysteresis. The hysteresis is intended to prevent an undefined reaction of alarm outputs when the measured value is close to the limit value. The hysteresis determines criteria for an alarm to be reset after a measurement value has exceeded a limit. The left diagram in [Figure 6-41](#) shows the behavior of a hysteresis at a greater than or equal to alarm limit. The right diagram in [Figure 6-41](#) shows the hysteresis behavior at a lower than or equal to alarm limit.

Figure 6-41: Hysteresis



Delay Enter a delay for the alarm limit. The entered value is the time between the detection of the alarm status and the output of the alarm.

Note

The delay function is available for A6500-TP cards with firmware version 3.0.x and higher.

Circuit mode Select here the operating principle of the hardware digital outputs DO 1 to DO 6. Circuit mode selection is not available for the software digital outputs.

Normally open With activated alarms, the output is conductive and an externally connected relay activated.

Normally closed With activated alarms, the output is disabled and an externally connected relay deactivated.

Additional parameter below the **Digital outputs** table:

Limit suppression Activate this function to suppress the alarm limits as soon as Channel OK is no longer present because of sensor failures. All other conditions (card

malfuctions and activated bypass) that could lead to the suppression of the alarms, remain unaffected by this parameter.

Note

Limit values suppressed means that the alarm outputs (digital outputs) are in their initial state (no “Alarm”).

Bypass affects Channel OK Click the checkbox to enable that a bypassed channel affects Channel OK. Behavior if a channel is bypassed:

- Box checked and bypass activated:

A digital output with **Data source → Channel OK - Combined** is switched into the channel not OK condition which depends on the configuration of **Circuit mode**.

Note

An enabled **Bypass affects Channel OK** only affects a digital output with **Data source → Channel OK - Combined**. An enabled **Bypass affects Channel OK** does not affect Channel OK of the single channels (sensor input 1a/1b to sensor input 4a/4b). With activated bypass, Channel OK is always switched off, independently of the setting **Bypass affects Channel OK**. All functions and display elements related to Channel OK such as OK LED, limit suppression, and current suppression react accordingly.

- Box not checked and bypass activated:

An activated bypass does not affect a digital output with **Data source → Channel OK - Combined**.

Example configuration


Example for alarm settings and digital output behavior:

Digital output 1 is assigned to a temperature measurement of channel 1. The output will switch when the limit 450°C is exceeded, and will switch off, when the temperature falls again below 430°C (450°C minus 20°C hysteresis). The circuit mode of this output is **Normally open**. This means in initial state the output is 0 V, in alarm state the output will be 24 V.

Digital output 2 is assigned to a process voltage measurement of channel 2 with 10 V measuring range. The output will switch when the limit 5 V is exceeded, and will switch off again, when the voltage falls below 4 V (5 V minus 1 V hysteresis). The circuit mode of this output is **Normally closed**. This means in initial state the output level is 24 V, in alarm state the output will switch to 0 V.

Digital output 3 is assigned to a temperature measurement of channel 3, subchannel B. The output remains in initial state as long as the temperature is within 100°C and 300°C. The alarm output will switch when the limit 300°C is exceeded or when the measuring value falls below 100°C (see [Figure 6-42](#)).

Figure 6-42: Alarm function "Window" - example



- A. Measuring value
- B. Limit 2: 300°C
- C. Hysteresis: 5°C
- D. Limit 1: 100°C
- E. No alarm
- F. Alarm
- G. Time

The output will switch off again, when the temperature falls below 295°C (300°C minus 5°C hysteresis) or increases over 105 °C (100°C plus 5°C hysteresis) and when a command or signal reset latch was sent to the card. The circuit mode of this output is **Normally open**. This means in initial state the output is 0 V, in alarm state the output will switch to 24 V.

6.6 Send and reload a configuration

6.6.1 Send a configuration

! CAUTION

The machine protection function of the card is disabled during sending of configurations with major changes, because of a reboot of the A6500-TP Card.

Note

Modbus requests are answered with **Server Device Busy (0x06)** when sending a configuration.

Whether or not a reboot is required depends on the changes to the configuration. The following changes do not require a reboot of the card:

- Names and texts
- Alarm limits
- Alarm related settings such as delay, latching, alarm hysteresis, and limit suppression.

Procedure

1. Ensure that there is an online connection between the A6500-TP card and AMS Machine Studio running on a PC or laptop.


AMS Machine Studio will automatically establish an online connection to the cards of the AMS 6500 ATG system as soon as there is a physical connection through the USB port of the A6500-CC Com Card or A6500-CP Com Card Pro of the system. At TCP/IP connection, click **Connect ATG-System** on the ribbon command bar of page **Home** to establish a connection.

Only A6500-CP: Log in as an **Operator** or an **Administrator**, and ensure that the key-switch is in the unlocked position. See [Enable system programming with A6500-CP communication card](#) or [Enable system programming with redundant A6500-CP communication cards](#).

2. Click **Send & close** in the ribbon command bar to send the configuration to the card.

A confirmation dialog opens in accordance to the boot requirement:


Figure 6-43: Confirmation – overwrite configuration without reboot



Check the box **Don't show again for this session** to send further configurations and reboot the card without confirming the dialog. This selection is reset when AMS Machine Studio is closed.

Click **Send** to overwrite the existing configuration without reboot.

Figure 6-44: Confirmation – overwrite configuration and reboot required



Check the box **Don't show again for this session** to send further configurations and reboot the card without confirming the dialog. This selection is reset when AMS Machine Studio is closed.


Click **Send & reboot** to overwrite the existing configuration and to reboot the A6500-TP Card afterward. The machine protection function of the card is disabled during the process.

The configuration editor automatically closes afterward.

A successful sent configuration is indicated by a message in the upper right corner of the software window. This message window will automatically disappear. Otherwise close it by clicking on the cross.

The Modbus registers are automatically updated according to the sent configuration. The successful update is also indicated by a message in the upper right corner (see [Figure 3](#)).

Figure 6-45: Modbus synchronization



Note

The Modbus registers are not automatically updated if an A6500-CC card is installed in the AMS 6500 ATG system that is protected by a password. In this case go to **Services → Modbus** and click **Update Modbus mappings** in the ribbon command bar to update the Modbus registers.

The card is ready to use when the **OK** LED on the card front shows a green steady light.

Note

Emerson recommends updating the time of the AMS 6500 ATG system after sending a configuration. This ensures that time stamps used for system events are up-to-date and therefore easier to assign. Select the AMS 6500 ATG system in the device tree and click **Set time** in the ribbon command bar. This is not necessary if the time is automatically synchronized with an SNTP server.

3. Only A6500-CP: Switch back the key-switch to the locked position to protect the AMS 6500 ATG system against unauthorized changes.

6.6.2

Reload a configuration


Once an online connection has been established, the configuration of all cards of a AMS 6500 ATG system are automatically loaded to AMS Machine Studio. Click **Reload** in the ribbon command bar if the configuration of the card must be loaded again.

7

Online View

After connection to an A6500-xR System Rack, the online view of the connected rack appears on the main page of AMS Machine Studio. [Figure 7-1](#) shows this view.

Figure 7-1: Overview online view



- A. Connected devices
- B. Main window with rack view
- C. A few details of the card selected from the rack overview

Select an A6500-TP card in the device tree or double click an A6500-TP card shown in the rack view to open the online view of the card. The online view has three pages, **Overview**, **Details**, and **Live data**. Several general details about the card, the location of the card, and the configuration are shown at the top of each online view page. There are two small additional icons, **Not in sync** and **No configuration**. These icons appear on the card symbol in the Network list if the card is not in sync or has no configuration.

Not in sync



A Temperature Process Card not in sync is marked with this symbol. A Temperature Process Card is "not in sync" if there is a draft configuration that has been not yet send to the card. For example, a digital output configuration of an A6500-TP cards has been changed and this change has been saved as draft.

1. Click the Temperature Process Card not in sync in the listed of connected devices below Network to select the card. The row will be colored blue.

2. Click **Configure** in the ribbon command bar to open the editor.

3. Check the configuration.

4. Click **Send & close** to synchronize the card.

The configuration is sent. The "not in sync" sign disappears after successful sending of the configuration.

No configuration



A Temperature Process Card without a configuration is marked with this symbol. This card state is also indicated by slowly flashing of the green OK LED on the front plate.


Note

Use online view to find the cause of any unexpected behavior of the card.

7.1 Overview


The content of the page depends on the configured measurements. **Overview** provides an overview of measuring results and card states (see [Figure 7-2](#)).

Figure 7-2: Overview



Measurement value

Figure 7-3: Measurement value




This graphic object displays the current value. The value is displayed as a numerical value and as a horizontal bar graph with measuring range, alarm limit indication (little black arrow), and hysteresis indication (little gray arrows). The bar graph changes color depending on the alarm state. The abbreviation in the upper right corner (DO) indicates an assigned digital output to the input. There is a measuring value object for each assigned digital output. If two digital outputs are assigned to one measurement value (input channel) than two measuring value objects are visible.

Bar graph color:

- Green: no alarm
- Red: alarm limit has been exceeded

Channel OK

Figure 7-4: Channel OK



This graphic object shows the channel state.

- A fault-free channel is indicated by a checkmark within a green solid circle
- A faulty channel is marked with a yellow warning triangle

Click on **Channel OK** to expand the object and get more information about the channel state (see [Table 7-1](#))

Table 7-1: Flags Channel OK

Flag	Meaning	Action
No Bypass		Bypass is not active
		Bypass is active Deactivate the bypass, seeBypass
Sensor		No fault detected.

Table 7-1: Flags Channel OK (continued)

Flag	Meaning	Action
		Sensor fault detected Check the sensor including wiring and connections
Card health		No fault detected. ---
		Card fault detected. For more details see graphic object "Card health".

Status flags

Figure 7-5: Status flags



These graphic objects indicate the state of several status flags. The number of flags depends on the card configuration.

- Limit suppression**
The flag is available if **Limit suppression** is enabled for the digital outputs. The solid circle is blue if the assigned limit suppression is active, otherwise the circle is gray.
- Current suppression**
The flag is available if a current output with enabled **Current suppression** is assigned to an input channel. The solid circle is blue if the assigned current suppression is active, otherwise the circle is gray.

Card health

Figure 7-6: Card health




This graphic object indicates the card health.

- A fault-free card is indicated by a checkmark within a green solid circle .
- A faulty card is marked with a yellow warning triangle .

Click on **Card health** to expand details about the card health. [Table 7-2](#) explains these flags.

Table 7-2: Card health flags


Flag	Meaning		Action
Software		No fault detected.	---
		An issue with the firmware has been detected by the internal watchdog.	Restart the card by pulling and plugging it. If the issue still exists, replace the card.
Hardware		No fault detected.	---
		An issue with hardware parts on the card has been detected by the internal supervision function.	Replace the card.
Temperature		No over temperature.	---
		The temperature, measured with the internal temperature sensor has exceeded the alert limit of 70°C.	Take appropriate measures to reduce the environmental temperature.
		The temperature, measured with the internal temperature sensor has exceeded the shut down limit of 80°C.	Emerson recommends to replace the card as parts might be stressed or damaged because of the high temperature. Take appropriate measures to reduce the environmental temperature.

Global flags**Figure 7-7: Global flags**

Click on **Global** to expand details about the bypass state. This graphic object indicates if the bypass of a digital outputs is active. The solid circle is blue if the bypass of the corresponding digital output is active, otherwise the circle is gray.

Digital outputs

Figure 7-8: Digital outputs



Click on **Digital outputs** to expand details about the digital output states. This graphic object shows the logical state of the digital outputs. The solid circle is blue if the configured condition is true, otherwise the circle is gray.

7.2 Details


Details displays measuring results together with status information and additional measuring details (see [Figure 7-9](#)). The content depends on the configured measurement application. For already described graphic objects see [Overview](#).

Note

The number of measurement value display fields and current output display field depends on the number of configured digital outputs and current outputs for one input channel.

For example, there are two limit values defined for one input signal and so two measurement value display field are shown marked with the assigned digital output (DO1 and DO 2).

Figure 7-9: Details



Service data

Figure 7-10: Service data

Service				
Up time	0.1 d	Cold starts	288	Curr. temp. 34.1 °C
Operation time	484.0 d	Configured	105	Min. temp. 15.6 °C
				Max. temp. 43.9 °C

This graphic object contains service data:

Up time Days in operation since the last power on. This counter is reset at each power on and with every new configuration.

Operation time Days in operation since the first power on.

Cold starts Number of cold starts. This counter increments each time the card powers on.

Configured Number configurations sent to this card.

Curr. temp. Current temperature of the card measured with the card internal sensor.

Min. temp. and Max. temp. Minimum and maximum temperature of the card measured with the card internal sensor.

Status values

Figure 7-11: Status values


Status values			
Sensor	11.88 °C	Resistance	104.6 Ω
min.	11.83 °C	min.	104.6 Ω
max.	11.91 °C	max.	104.6 Ω

The **Status values** display field shows the current measurement value together with the measured input signal. The lines below show minimum and maximum measurement values detected during operation. The units of the displayed values depends on the configuration. These values can be a good help on recognition of errors.

The Minimum and maximum values are continuously measured during operation and remain displayed until the command **Reset min/max values** is given through a digital input or the button in the ribbon command bar.

Current output

Figure 7-12: Current output




This graphic object shows the current value of the current output.

Calculation

The result of the calculation is displayed. Additional graphic objects are added if digital outputs or current outputs are assigned to the calculation result.

Figure 7-13: Calculation



7.3

Live data

This display screen shows trend diagrams of all channels simultaneously. For example, see [Figure 7-14](#) with time waveforms of channels 1A and channel 2.

Use the control elements in the upper right corner of each diagram to change the diagram view. [Table 7-3](#) explains the control elements. Right-click somewhere on the diagram to reset the view changes.

Table 7-3: Diagram control elements

Control element	Function
	<p>Zoom Use this function to enlarge an interesting part of the diagram. Click the zoom icon to activate the zoom function. The button is colored light blue if zoom is activated otherwise the button is gray. Place the mouse cursor close to the area of interest, left-click and hold. Move the mouse to frame the area of interest. Release the mouse button to enlarge the selected area.</p>
	<p>Move Use this function to move the entire view. Click the move icon to activate the function. The button is colored light blue if move is activated, otherwise the button is gray. Left-click an arbitrary point in the diagram and hold. Move the view to the desired position and release the mouse button to place the view at that point.</p>
	<p>Zoom in Use this function to stepwise enlarge the diagram view. Click the zoom in icon to activate the function. The button is colored light blue if zoom in is activated otherwise the button is gray. Left-click an arbitrary point in the diagram view. At every click, the diagram view is enlarged.</p>
	<p>Zoom out Use this function to stepwise reduce the diagram view. Click the zoom out icon to activate the function. The button is colored light blue if zoom out is activated otherwise the button is gray. Left-click an arbitrary point in the diagram view. At every click, the diagram view is reduced.</p>

Figure 7-14: Measuring results channels 1A and 2, "Time waveform"

In this diagram, the trends of channels 1A and 2 are visualized as examples. This visualization function shows the trends of all configured channels of this card. Unconfigured or deactivated channels will not appear in this diagram.

The diagrams show actual measuring results over a time period of 100 seconds. The trend diagrams are only displayed, the results are not saved on hard disk. To store measuring data for later analysis purpose, transmit the data to another computer via Modbus RTU, Modbus TCP/IP, or OPC UA.

7.4


Online commands

The A6500-TP card related commands are described. For description of all other buttons of the ribbon command bar see operating manual "AMS Machine Studio - General Functions" (MHM-97879). [Figure 7-15](#) the ribbon command bar with the marked online commands.

Note

Ensure that there is an online connection to the card before using these commands

Figure 7-15: Command buttons



Identify


Figure 7-16: Button "Identify"



Click **Identify** to identify the card within the rack. This command starts a LED sequence on the front plate of the card. It runs for approximately 15 seconds and stops automatically afterward.

Reset latch

Figure 7-17: Button "Reset latch"



Click **Reset Latch** to open a selection list with different options for resetting latched alarms:

Reset latch 1 to Reset latch 16

Click one of these options to reset latched alarms defined for the respective digital output (digital output 1 to digital output 16).

Reset latch all

Click this option to reset all latched alarms at once.

Reset min/max values

Figure 7-18: Button "Reset min/max values"



Click **Reset min/max values** to reset stored minimum or maximum values. This command resets the following status values:

- Minimum measured temperature.

- Maximum measured temperature.
- Minimum measured process values.
- Maximum measured process values.
- Minimum measured input signal.
- Maximum measured input signal.

7.5

LEDs on the front panel

The A6500-TP Temperature Process Cards are fitted with five LEDs on the front panel.

- **OK**
Green LED to indicate the status of the card. When this LED lights up, hardware and software condition of the card are OK. This LED also indicates channel OK of all active sensor inputs. The LED will be switched off if any sensor input fault is detected.
- **Alarm**
Four red alarm LEDs – one for each of the channels. If one of the four channels is in alarm condition, the relevant LED lights up.

Note

Alternate flashing of the alarm LEDs indicates that the card is in the bootloader. If the card sticks in this condition – the LEDs still flash alternately after 10 seconds – set the card to factory default (see [Ribbon command bar](#)) and configure the card anew.

8

Applications and functions

8.1

Electrical temperature measurement

The measurement of temperature has a great importance in supervising industrial processes. The sensors applied for this measurement define the temperature range, accuracy of the measurement, as well as chemical and physical resistances against environmental conditions at the place of measurement.

This chapter describes temperature measurements with thermocouples and **Resistance Temperature Detectors (RTDs)** in combination with A6500-TP Temperature Process Cards.

Resistance temperature detectors take advantage of the fact that the resistance of electrical conductors increases with the temperature (PTC resistor). Most popular RTDs are Pt100 resistors, because resistance elements of Platin are precise and have high long-term stability. RTDs for temperature measurements are mainly used for temperatures up to about 600°C. For higher temperatures, thermocouples are used primarily.

8.2

Temperature measurement with RTDs

Resistance elements for temperature measurements with A6500-TP monitors are:


- Pt100, basic resistance 100 Ω / 0°C
- Ni100, basic resistance 100 Ω / 0°C
- Ni120, basic resistance 120 Ω / 0°C
- CU10, basic resistance 10 Ω / 25°C

For temperature measurements, the A6500-TP Temperature Process Card supplies the RTD with an impressed current of 0.5 mA (3-pole connection 0,25 mA). Its resistance is calculated by the measured voltage drop over the RTD. From this value, the program determines the exact temperature value with the help of a linearization table.

Connection types

RTDs can be connected to the A6500-TP card in 2-pole, 3-pole, or 4-pole connection.


Figure 8-1: 2-pole connection of RTDs



This connection type causes a high error in measurement because the measuring device measures the resistance of the PT100 together with the cable resistance R_L (see [Figure 8-1](#)). This means, the indicated temperature is higher than the actual temperature of the Pt100. This measurement error depends on the length of the cable and the environmental temperature of the cable.

To compensate this error, enter an offset value in the configuration parameters in field **Temperature offset [°C]** in the editor **Configuration**.


Figure 8-2: Configuration cable compensation RTD measurement




The correction value is calculated by determining the cable resistance and calculating the appropriate temperature deviation with the help of a Pt100 resistance table.

A 3-pole connection is a type of application that is often found in older installations (see [Figure 8-3](#)). With this installation, the program compensates the cable resistance automatically by measuring the resistance of one cable core. Since the wires in multicore cables usually have the same resistance, this application measures the correct resistance of the RTD.

Figure 8-3: 3-pole connection of RTDs



A 4-pole connection of RTDs is the most precise way to measure for this application (see [Figure 8-4](#)). The voltage drop is measured directly across the Pt100 resistor, regardless of cable type and cable length. The measurement error is reduced to the minimum.

Figure 8-4: 4-pole connection of RTDs**Note**

Cold junction compensation with Cu 10 RTDs is only possible with a 4-pole connection mode.

Pt100, Ni100, and Ni120 RTDs for cold junction compensation may be applied in 2-pole, 3-pole, or 4-pole connection mode.

The signal inputs for process signal measurement are electrically isolated from system supply. The correct EMC compliant grounding and shielding of signal cables are described in the operating manual of the A6500-xR System Racks.

8.3

Temperature measurement with thermocouples

Thermocouples consist of two particular metals welded together at one point, called the hot junction point. If this point is exposed to temperatures, one of the metals emits electrons to the other materials. This results in a thermo-voltage of a few millivolts. The higher the temperature, the greater the thermo-voltage between the two metals.

Detection of temperatures with thermocouples are principally punctual contact measurements at the tip of the sensors. The typical scope of application for the use of thermocouples is for temperatures above 600°C. Because of a better accuracy and long-term stability, measurements of temperatures up to this value are usually covered with RTDs.


To use the signal of thermocouples for temperature measurement, it must be lead to signal inputs of measuring devices, such as the A6500-TP card. When thermocouples wires are connected to other metals, for example, copper wires, another thermo-voltage arises at this junction point, the cold junction point.

The calculation of the temperature requires only the thermo-voltage of the hot junction point (the tip of the thermocouple). For this reason, the thermo-voltage from the cold junction point must be compensated. This is done by measuring the temperature from this point and compensate this unwanted thermo-voltage.

One method for cold junction compensation is to place the connection point in a closed cabinet or box with a constant temperature, and define this temperature in the configuration software (see [Figure 8-5](#)). With this application, any change of the cold

junction temperature will directly influence the measuring result. Details for the input of configuration parameters you can find in [Configuration](#).


Figure 8-5: Cold junction compensation, constant temperature



- A. Hot junction point = measuring point
- B. Thermocouple
- C. Cold junction point
- D. Metal 1
- E. Metal 2
- F. Constant junction temperature (δ)
- G. Copper wires
- H. Temperature difference
- I. Voltage signal difference of thermo-voltages between metal 1 and metal 2

Another way for the cold junction compensation is the measurement of the temperature inside the terminal box with an RTD, for example, a Pt100 (see [Figure 8-6](#)).

Figure 8-6: Cold junction compensation, temperature measured with Pt100



- A. Hot junction point = measuring point
- B. Thermocouple
- C. Cold junction point
- D. Metal 1
- E. Metal 2
- F. Junction temperature (delta)
- G. Copper wires
- H. Temperature difference
- I. Measurement of junction temperature with Pt100
- J. Voltage signal difference of thermo-voltages between metal 1 and metal 2

The signal inputs for process signal measurement are electrically isolated from system supply. The correct EMC compliant grounding and shielding of signal cables are described in the operating manual of the A6500-xR System Racks.

Detailed descriptions on the configuration you can find in [Configuration](#).

8.4

Measurement of process parameters

Measurement of process parameters are necessary to supervise and optimize any kind of industrial processes. The A6500-TP Temperature Process Cards were designed to measure the following standard signals:

- 0 to 1 V
- 0 to 10 V
- 0/4 to 20 mA

The measuring results can be visualized, supervised on limit exceeding, and via a communication cards transmitted to analysis systems or host computers for further processing.

During the configuration, the input signals can be scaled, shifted, and output in form of analog signals 0/4 to 20 mA for external indicators or systems.

The signal inputs for process signal measurement are electrically isolated from system supply. The correct EMC compliant grounding and shielding of signal cables are described in the operating manual of the A6500-xR System Racks.

Detailed descriptions on the configuration you can find in [Configuration](#).

8.5

Channel OK supervision

The condition supervision function checks the functionality of card and input signals. This function ensures that invalid measurements are indicated and, if necessary, alarms are deactivated. The indication takes place through:

- The green OK LED on the front plate. The Channel OK supervision of all channels is assigned to the OK LED. The LED is switched off as soon as one channel detects a fault.
- A digital hardware output configured for Channel OK
- Setting of the assigned current output to 0 mA, provided that the current output is configured for the output range of 4 to 20 mA or 20 to 4 mA and the current suppression is activated.
- Modbus and OPC UA interfaces
- Online View of the card in AMS Machine Studio.

Functional disturbances are divided into two groups. Disturbances that affect the monitor are allocated to the group of card errors. Sensor or input signal disturbances are allocated to the group of channel errors.

Card disturbances:

- Firmware errors
- Internal card errors
- Exceeding the temperature danger limit (measured with the internal temperature sensor of the card)

Channel disturbances:

- Sensor errors
- Signal errors

The detection of the sensor status by the Channel OK supervision depends on the connected and configured sensor type. See [RTD and Thermocouple](#) and [Process signals](#).

OK LED

Table 8-1: OK LED

Status OK LED	Card based (all channels)			Channel based		
	Description	Current output 4 to 20 mA ¹ and suppression	Digital output with Data Source: Channel OK - Combined	Description	Assigned current output 4 to 20 mA ¹ and suppression	Digital output with Data Source: Channel OK - Combined
Off ²	Card error ³	0 mA	Depending on configuration, see Table 8-2	Channel error ⁴	0 mA	Depending on configuration, see Table 8-2
	Temperature danger ³	0 mA		Active bypass ⁴	0 mA	Depending on configuration, see Table 8-2
Steady light	OK status	No influence		OK status	No influence	Depending on configuration, see Table 8-2
Slow flashing ²	Normal start phase	0 mA				
	Card not configured	0 mA				
Fast flashing ²	Temperature alert	No influence	Depending on configuration, see Table 8-2			
	Wait after card error ⁴	0 mA	Off			

¹ Or 20 to 4 mA.

² More precise information concerning the cause is available in the Online View.

³ Digital outputs are suppressed (initial state of the digital outputs).

⁴ If limit suppression is active, the digital outputs are in their initial state.

Digital hardware output – Channel OK - Combined

The output state of a digital hardware output with Data source → Channel OK - Combined assigned, depends on the configured Circuit mode. See [Table 8-2](#)

Table 8-2: Output state depending on selected circuit mode

Channel OK state	Circuit mode	Status indication Online View	Digital output state
OK	Normally open	Blue circle	On (24 V)

Table 8-2: Output state depending on selected circuit mode (continued)

Channel OK state	Circuit mode	Status indication Online View	Digital output state
	Normally closed	Blue circle	Off (0 V)
Not OK	Normally open	Gray circle	Off (0 V)
	Normally closed	Gray circle	On (24 V)

RTD and Thermocouple

The A6500-TP Temperature Process Card supervises the current flow of the sensor circuit to detect short circuits or open connectors (cable break). A detected sensor error is indicated as described above. The channel error message is reset as soon as the supervised current is in the good range again.

Note

Thermocouples can only be supervised for open connectors (cable break). Short circuit detection is not possible for thermocouples.

When the channel used for the cold junction compensation (CJC) detects a failure, the respective channel and also all of the associated thermocouple channels will turn off Channel OK. Only fully operational channels indicate Channel OK. If more than one Channel OK is missing at the same time, this may be caused by a channel error on the channel used for the CJC sensor.

Process signals

The A6500-TP Temperature Process Card supervises the configured process input signal. If the input signal exceeds the upper limit value (see [Table 8-3](#)) or falls below the lower limit value (see [Table 8-3](#)), a channel error message is generated. The channel error message is reset as soon as the input signal is in the good range again.

Table 8-3: Process signals – Channel OK limits

Analysis range	Channel OK limit	
	Lower	Upper
0 to 1 V	-0.1 V	1.1 V
0 to 10 V	-0.1 V	10.1 V
0 - 20 mA	-0.2 mA	21.0 mA
4 - 20 mA	3.6 mA	21.0 mA

8.6 Bypass

The four input channels of the A6500-TP card can be bypassed channel by channel. Different interfaces are available to activate a bypass:


1. Digital inputs (see [Digital inputs](#))
2. Software inputs (Modbus and OPC UA), see [Digital inputs](#)

⚠ DANGER

Bypassed inputs channels are not part of the machine protection.

The source of the bypass activation is displayed in the online view of AMS Machine Studio, if the bypassed card is selected.

Figure 8-7: Active bypass notification



With an activated bypass the related input channel is switched off and assigned outputs are switched to their initial state. The initial state depends on the configured operating principle (normally open- or normally closed-circuit mode) of the digital outputs.

Whether the Channel OK output (digital output with **Data source** set to **Channel OK - CombinedChannel OK -Combined**) is affected or not depends on the configuration of the parameter **Bypass affects Channel OK**. See [Digital outputs](#).

The alarm states provided through the Modbus or OPC UA interface are also affected by the bypass. The online display of the measuring value is grayed out but still indicating the current value. An active bypass is indicated by:

- Modbus registers and OPC UA data points
- Online display
- Digital output with **Data source** → **Channel OK - Combined**
If **Bypass affects Channel OK** is activated.
- Channel OK

All functions and display elements related to Channel OK react accordingly, see [Table 8-1](#).

9

Replace a Temperature Process Card

Follow the steps listed below if a A6500-TP Temperature Process Card needs to be replaced, for example, due to a defect.

Procedure

1. **⚠ CAUTION**

Any work at the system may impair machine protection.

Save the card configuration – if possible.

- a) Connect the computer through USB or Ethernet connection to a communication card.
- b) Start AMS Machine Studio. If connected through USB, the software automatically connects to the AMS 6500 ATG rack and opens the rack view. If connected through Ethernet, click **Connect ATG-System** to establish the connection.
- c) Double-click the card to be replaced. The online view of the card opens.
- d) Click **Configure** to open the configuration of the card.
- e) Save the configuration file. Go to **File** and select **Save as**.
- f) Go back to the editor and close it.
Do not close AMS Machine Studio.

2. At the System Rack, unfasten both screws at the front plate of the card to be replaced (see [Figure 2](#)).
3. Remove the card from the slot.
4. Install the new card.
5. Fasten the screws at the front plate to secure the card in the slot.
The card will be automatically detected by AMS Machine Studio if the System Rack is still powered.
6. Load the configuration from the memory of the computer into the card. If, due to a defect, there was no possibility of reading the configuration from the card to be replaced, use a back-up configuration file or create a new configuration.
 - a) Select the replaced card in the rack view. Double-click the new card to open the Online View.
 - b) Click **Configure** to open the configuration of the card.
 - c) Open the saved configuration file. Go to "File" and select **Open**.
 - d) Click **Send & close** to load the configuration to the new card.
After a successful sending of the configuration the editor automatically closes.

Now, the new card is ready for operation.

10 Functional check and maintenance

10.1 Functional check

⚠ CAUTION

Any work a the system may impair machine protection.

10.1.1 Check of the measuring functions

After installation and configuration check the function of the entire system. A complete functional check includes:

- Check of correct polarity of sensors and cable connectivity. This includes checking all signal paths from the sensors to the card inputs.
- Examine actual measurement indications on exceeding of measuring ranges.
- Read the output indications and examine the correct scaling.
- Check the correct wiring at the terminal blocks. Different measuring functions require individual connections at the input connectors.
- Check the configuration and that the parameters were loaded to the cards. When the configuration is finished, save the configuration files.
- Check the signal quality at the input terminals with respect to interferences. This applies especially in case of unstable measuring indications and for measurements with thermocouples. Signals of these sensors are very low, disturbances on the signal lines may lead to unstable indications or even to unwanted triggering of alarms.

In some cases it may be useful, to open display screen **Details** to get detailed information about the measurement.

If a problem still exists, Emerson recommends resetting the system and enter parameters anew (see [Delete configuration](#)).

10.1.2 Check of thermocouple measurements

Check the configuration of the channel and that the parameter set was loaded to the protection card. Open the online indication with the measuring results, and check whether the temperature value is within the expected range compared to indications of other devices.

If the indicated temperature is too low or too high, this could be caused by a wrong linearization due to a wrong thermocouple type. Another reason could be a faulty polarization of the thermocouple, a wrong compensating line, or a wrong temperature for the cold junction point.

Measure the thermocouple signal at the input connectors or read the signal level in the online display of the configuration software, application window **Details** - display field

Status values. This field shows the signal level of the thermocouple [mV], which can be used for the functional check.

Compare signal level of the thermocouple and environmental temperature with a temperature table of the thermocouple.

- If the input signal shows any kind of interference, to check the correct cable shielding to ensure a correct measurement.
- Check the cold junction temperature and the correct configuration of this parameter. If the cold junction temperature is measured with an RTD, check the correct wiring and the correct configuration of this sensor.
Compensating lines of materials that do not match to the thermocouple type, causes the formation of another two unwanted thermocouples, and thus a corruption of the measuring signal. Thermocouples and compensating cables have to be of same material in any case.
- If the input terminals show a signal level, much higher than the normal signal range of the sensor, this might be caused by a broken thermocouple. Measure the resistance of the sensor with an ohmmeter between the input terminals. With an intact thermocouple, you should measure a very low resistance of between 0,2 Ω to approximately 5 Ω per meter cable length, depending on the sensor type.
If you measure a resistance of more than about 500 Ω , the thermocouple is broken and must be replaced.

10.1.3 Check of RTD measurements

Disconnect the RTD sensor from the A6500-TP channel to be tested and measure the resistance of the RTD with an ohmmeter.

Use [Table 10-1](#) for a rough test of the RTDs by means of the measured resistance.

Table 10-1: Table of RTD resistance values

Sensor type	0°C	10°C	20°C	30°C	40°C
Pt100	100.00 Ω	103.90 Ω	107.79 Ω	111.67 Ω	115.54 Ω
Ni100	100.00 Ω	105.60 Ω	111.30 Ω	117.10 Ω	123.00 Ω
Ni120	120.00 Ω	124.68 Ω	129.35 Ω	134.00 Ω	138.65 Ω
Cu10	9.04 Ω	9.42 Ω	9.81 Ω	10.19 Ω	10.58 Ω

Reconnect the RTD and compare the measured resistance with the displayed resistance (application window **Details**, display field **Status values**). Both values must be identical as close as possible.

If the difference between measured resistance at, for example, 20°C and the values in the table above exceeds the permissible limit with respect to the equipment accuracy, the sensor must be replaced.

10.1.4 Check of process value measurements

The connection of process values to the A6500-TP card is made to terminal pins different to the connection of RTDs and thermocouples. If the measurement is not running properly, first check the correct connection.

The measured input signal can be read in the online display of the configuration software, application window **Details** - display field **Status values**. This field shows the signal level together with the scaled process values and their minimum and maximum values.

In case of problems, these indications shows, whether the problem is located in the measuring system or if it is coming from the connected external device. The voltage level in the left column of display field **Status values** has to be identical with the signal at the terminal pins. If not, the measuring of the card is not working properly and has to be replaced.

10.2 Maintenance

The A6500-TP Temperature Process Card does not require any maintenance during normal operation.

11 Technical data

Only specifications with indicated tolerances or limit values are obligatory. Data without tolerances or without error limits are informative data and not guaranteed. Technical modification, especially of the software, are subject to changes without notice. If not specified otherwise, all data are referred to an environmental temperature of +25°C.

11.1 Power supply

Nominal voltage	+24 V	redundant supply voltage inputs protected against polarity reversal
Permissible voltage range	+19 V to +32 V DC	in case of a single failure, supply voltage must not exceed the level of IEC 60204-1 or IEC 61131-2 (SELV/PELV)
Oversupply protection	>+33 V DC	card shuts down at oversupply condition
Power consumption	5 W	Test condition: all current outputs at full load, all outputs active (exterior load currents of digital outputs must be considered separately)

11.2 Signal input

Sensor and process signal input		
Number of temperature sensor inputs	8	independently configurable for different temperature sensors or process signal inputs nonreactive short circuit proof
Number of process signal inputs	4	
Input resolution	24 bit ADC	
Input isolation		the four inputs are galvanically isolated against each other based on levels of IEC 60204-1 respectively IEC 61131-2
Signal input	0 to 11 V	Process input
	0 to 20 mA	
	resistance temperature sensor / thermometer	
Rated voltage at current input	2.4 V	
Rated power at current input	50 mW	

Sensor and process signal input		
Rated voltage at voltage input	0.11 mA	
Rated power at voltage input	1.2 mW	

Process input voltage		
Range	0 to 10 V	
Accuracy	$\pm 1\%$ of full scale	
Impedance	>100 k Ω	
Temperature drift	$\pm 0.5\%$ of full scale	within operating temperature range of -20°C to +70°C

Process input current		
Range	0/4 to 20 mA	current limiter
Accuracy	$\pm 1\%$ of full scale	
Impedance	<200 Ω	
Temperature drift	$\pm 0.5\%$ of full scale	within operating temperature range of -20°C to +70°C

RTD sensor input		
Type	Pt100, Ni100, Ni120, Cu10	Pt100 ($\alpha = 0.00385$) Ni100 ($\alpha = 0.00618$) Ni120 ($\alpha = 0.00672$) Cu10 ($\alpha = 0.00427$)
Technology	2-, 3-, and 4-wire	Cu10 is not applicable in 2-wire and 3-wire technology
Accuracy	$\pm 1\text{ K}$	
Excitation current	500 μA	for 3-wire 2 x 250 μA
Cable resistance	<120 Ω	per wire and if ex-application, including possible safety barrier impedance
Temperature drift	$\pm 1\text{ K}$	within operating temperature range of -20°C to +70°C

Thermocouple input		
Type	E, J, K, N, T	
Accuracy	$\pm 1\text{ K}$	
Cold junction compensation	exterior	use RTD sensor input for cold junction compensation (CJC)
Capacity	<10 μF	including sensor cable

Thermocouple input		
Temperature drift	±1 K	within operating temperature range of -20°C to +70°C

11.3 Digital input

Number of inputs	2	
Logic low level	0 to 3 V	active
Logic high level	13 to 32 V, open	not active
Load	<1 mA	
Rated current	1 mA	
Rated power	24 mW	

11.4 Outputs

Current output		
Number of outputs	4	
Range	0/4 to 20 mA	
Accuracy	±1% of full scale	
Load	<500 Ω	
Rated voltage	10 V	
Rated power	0.2 W	
Temperature drift	±1% of full scale	within operating temperature range of -20°C to +70°C

Digital output		
Number of outputs	6	
Type	normally open	equivalent to SPST protected against polarity reversal
Voltage capability	19 V to 32 V DC	
Maximum load	100 mA	
Rated current	100 mA	
Rated power	2.4 W	
Turn-on/turn-off time	<5 ms	at 20kΩ load (without alarm detection time as configured delays, filter settings)

11.5 Data interface

Communication bus	RS 485	according EIA485 standard
Bus termination	exterior	bus termination according to EIA485 can be provided externally

11.6 Mechanical design and environmental conditions

Table 11-1: Mechanical design

Rack slot	3RU/6HP	
Material front panel	aluminum, clear anodized	
Board dimensions	100x160 mm	euro-card format conform to IEC 60297
Board coating	Airborne contaminants resistance	ISA-S71.04-1985 airborne contaminants class G3, Conformal Coating
	Material: HumiSeal® 1B31 EPA	according to IPC-CC-830B and IPC-A 610
Card connector	type F48 male	according to IEC 60603-2
Status indication	LED (3 mm)	one green OK LED and four red Alarm LEDs at front panel
Weight	approximately 200 g	without packaging
Overall dimensions		see Figure 11-1


Table 11-2: Environmental conditions

Protection class	IP20	according to IEC 60529 rack mounted, otherwise IP00
Approval class for general safety	Class 2253 01	industrial automation products
	Class 2253 81	industrial automation products - (certified to U.S. standards)
Allowed degree of pollution	Category 2	according to IEC 61010-1
Operating temperature	-20°C to +70°C	with forced cooling ¹
	-20°C to +55°C	without forced cooling
Storage temperature	-40°C to +85°C	
Relative humidity	5 to 95%	noncondensing
Shock	150 m/s ²	according to IEC 60068-2-27, 4000 shocks per axis

Table 11-2: Environmental conditions (continued)

Vibration	0.15 mm 20 m/s ²	10 to 55 Hz 55 to 150 Hz according to IEC 60068-2-6, float sinus, three axis
Operating altitude	<2000 m	above sea level
Environmental area	Indoor use only	
External devices		in case of a single failure, externally connected devices must not exceed the level of IEC60204-1 or IEC 61131-2

1 An airflow of $\geq 440 \text{ m}^3/\text{h}$ is required.

Figure 11-1: Dimensions

A. 3 RU

B. 6 HP

All dimensions in mm

12 Certificates



EU-Declaration of Conformity (Translation)



**We: epro GmbH, Jöbkesweg 3, 48599 Gronau
declare under our sole responsibility that following product(s):**

Product designation: AMS 6500 ATG
Product description: Protection system for rotating equipment with integrated prediction capabilities
Part numbers
A6500-CC
A6500-CP
A6500-UM
A6500-TP
A6500-RC
A6500-SR
A6500-RR
A6500-FR

are in conformity with the terms of the directives mentioned below including any amendment valid at the date of declaration:

2014/30/EU Electromagnetic compatibility
2014/34/EU Equipment and protective system intended for use in potentially explosive atmospheres
2011/65/EU The restriction of the use of certain hazardous substances in electrical and electronic equipment

Following harmonized standards have been applied:

2014/30/EU	EN 61326-1	Electrical equipment for measurement, control and laboratory use. EMC requirements.
2014/34/EU	EN 60079-0	Part 1: General requirements Explosive atmospheres -
	EN 60079-7	Part 0: Equipment - General requirements Explosive atmospheres -
2011/65/EU	EN 63000	Part 7: Equipment protection by increased safety "e" Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

For the type examination according to EN 60079-0 and EN 60079-7 the following notified body has been involved:


DEKRA EXAM GmbH
Type examination certificate BVS 16 ATEX E 016 U

Authorized person for technical documentation:

Bruno Hecker, Jöbkesweg 3, 48599 Gronau

Gronau, 11 February 2025
Place, Date


Managing Director


Quality



EU-Konformitätserklärung (Original)



Wir: epro GmbH, Jöbkesweg 3, 48599 Gronau

erklären in alleiniger Verantwortung, dass folgende Produkte:

Produktbezeichnung: AMS 6500 ATG

Produktbeschreibung: Schutzsystem für rotierende Maschinen mit integrierten Diagnosemöglichkeiten

Artikelnummern: A6500-CC
A6500-CP
A6500-UM
A6500-TP
A6500-RC
A6500-SR
A6500-RR
A6500-FR

den Bestimmungen der unten genannten Richtlinien, einschließlich deren zum Zeitpunkt der Erklärung geltenden Änderungen, entsprechen:

2014/30/EU Elektromagnetische Verträglichkeit

2014/34/EU Geräte und Schutzsysteme zur bestimmungsgemäßen Verwendung in explosionsgefährdeten Bereichen

2011/65/EU Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten

Folgende harmonisierte Normen wurden angewandt:

2014/30/EU EN 61326-1 Elektrische Mess-, Steuer-, Regel- und Laborgeräte – EMV Anforderungen - Teil 1: Allgemeine Anforderungen

2014/34/EU EN 60079-0 Explosionsgefährdete Bereiche - Teil 0: Betriebsmittel – Allgemeine Anforderungen

EN 60079-7 Explosionsgefährdete Bereiche -

Teil 7: Gerätenschutz durch erhöhte Sicherheit "e"

2011/65/EU EN 63000 Technische Dokumentation zur Beurteilung von Elektro- und Elektronikgeräten hinsichtlich der Beschränkung gefährlicher Stoffe

Für die Baumusterprüfung nach EN 60079-0 und EN 60079-7 ist folgende Benannte Stelle eingeschaltet worden:

DEKRA EXAM GmbH
Baumusterprüfnummer BVS 16 ATEX E 016 U

Bevollmächtigter für die Technische Dokumentation:

Bruno Hecker, Jöbkesweg 3, 48599 Gronau

Gronau, 11. Februar 2025
Ort, Datum

Geschäftsleitung

Qualitätsmanagement



UKCA-Declaration of Conformity

We, the manufacturer: epro GmbH, Jöbkesweg 3, 48599 Gronau, Germany
declare under our sole responsibility that following product(s):

Product designation:	AMS 6500 ATG
Product description:	Protection system for rotating equipment with integrated prediction capabilities
Part numbers	A6500-CC A6500-CP A6500-UM A6500-TP A6500-RC A6500-SR A6500-RR A6500-FR

are in conformity with the terms of the directives mentioned below including any amendment valid at the date of declaration:

- S.I. 2016 No. 1091 Electromagnetic Compatibility Regulations 2016
- S.I. 2016 No. 1107 Equipment and Protective Systems Intended for use in Potentially Explosive Atmospheres Regulations 2016
- S.I. 2012 No. 3032 The restriction of the use of certain hazardous substances in electrical and electronic equipment

Following standards have been applied:

- S.I. 2016 No. 1091 EN 61326-1 Electrical equipment for measurement, control and laboratory use. EMC requirements. Part 1. General requirements
- S.I. 2016 No. 1107 EN 60079-0 Explosive atmospheres -Part 0: Equipment- General requirements
EN 60079-7 Explosive atmospheres - Part 7: Equipment protection by increased safety "e"
- S.I. 2012 No. 3032 EN IEC 63000 Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances


For the type examination according to EN 60079-0 and EN 60079-7 the following notified body has been involved:

DEKRA Testing and Certification GmbH
 Type examination certificate BVS 16 ATEX E 016 X

Authorized person for technical documentation:
 Bruno Hecker, Jöbkesweg 3, 48599 Gronau, Germany

Authorized Representative:

Emerson Process Management Limited,
 company No 00671801
 Meridian East,
 Leicester
 LE19 1UX, United Kingdom
 Regulatory Compliance Department
 email:ukproductcompliance@emerson.com
 Phone: +44 11 6282 23 64




M. Fräzner
 Managing Director

B. Hecker
 Quality

Place, Date: Gronau, 11 February 2025



Emerson Process Management
1100 W. Louis Henna Blvd.
Round Rock, TX 78681

Statement Regarding the China RoHS Compliance of Emerson Product – A6500-UM

Please refer to Table 1 for the names and contents of the toxic or hazardous substances or elements contained in Emerson products.

Table 1: Names and Contents of Toxic or Hazardous Substances or Elements

表1：有毒有害物质或元素的名称及含量

部件名称 Part Name	有毒有害物质或元素 Toxic or hazardous Substances and Elements					
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr (VI))	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
印刷电路板组装 PC BD ASSY	X	0	0	0	0	0
面板 FACE PLATE	0	0	0	0	0	0
印刷电路板组装支持 PC BD ASSY SUPPORT	0	0	0	0	0	0
O 表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下 O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.						
X 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.						
环保期限 (EFUP) 的产品及其部件是每个列出的符号，除非另有标明。使用期限只适用于产品在产品手册中规定的条件下工作 The Environmentally Friendly Period (EFUP) for the product and its parts are per the symbol listed, unless otherwise marked. Use Period is valid only when the product is operated under the conditions defined in the product manual.						

James McFerrin
Environmental Compliance Manager PSG
T 512 832 3271 E james.mcferrin@emerson.com



Emerson Process Management
1100 W. Louis Henna Blvd.
Round Rock, TX 78681

Statement Regarding the China RoHS Compliance of Emerson Product – A6500-TP

Please refer to Table 1 for the names and contents of the toxic or hazardous substances or elements contained in Emerson products.

Table 1: Names and Contents of Toxic or Hazardous Substances or Elements

表1：有毒有害物质或元素的名称及含量

部件名称 Part Name	有毒有害物质或元素 Toxic or hazardous Substances and Elements					
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr (VI))	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
印刷电路板组装 PC BD ASSY	X	0	0	0	0	0
面板 FACE PLATE	0	0	0	0	0	0
印刷电路板组装支持 PC BD ASSY SUPPORT	0	0	0	0	0	0
O 表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下 O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.						
X 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.						
环保期限 (EFUP) 的产品及其部件是每个列出的符号，除非另有标明。使用期限只适用于产品在产品手册中规定的条件下工作 The Environmentally Friendly Period (EFUP) for the product and its parts are per the symbol listed, unless otherwise marked. Use Period is valid only when the product is operated under the conditions defined in the product manual.						

James McFerrin
Environmental Compliance Manager PSG
T 512 832 3271 E james.mcferrin@emerson.com



Emerson Process Management
1100 W. Louis Henna Blvd.
Round Rock, TX 78681

Statement Regarding the China RoHS Compliance of Emerson Product – A6500-RC

Please refer to Table 1 for the names and contents of the toxic or hazardous substances or elements contained in Emerson products.

Table 1: Names and Contents of Toxic or Hazardous Substances or Elements

表1：有毒有害物质或元素的名称及含量

部件名称 Part Name	有毒有害物质或元素 Toxic or hazardous Substances and Elements					
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr (VI))	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
印刷电路板组装 PC BD ASSY	X	0	0	0	0	0
面板 FACE PLATE	0	0	0	0	0	0
印刷电路板组装支持 PC BD ASSY SUPPORT	0	0	0	0	0	0
O 表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下 O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.						
X 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.						
环保期限 (EFUP) 的产品及其部件是每个列出的符号，除非另有标明。使用期限只适用于产品在产品手册中规定的条件下工作 The Environmentally Friendly Period (EFUP) for the product and its parts are per the symbol listed, unless otherwise marked. Use Period is valid only when the product is operated under the conditions defined in the product manual.						

James McFerrin
Environmental Compliance Manager PSG
T 512 832 3271 E james.mcferrin@emerson.com



Emerson Process Management
1100 W. Louis Henna Blvd.
Round Rock, TX 78681

Statement Regarding the China RoHS Compliance of Emerson Product – A6500-CC

Please refer to Table 1 for the names and contents of the toxic or hazardous substances or elements contained in Emerson products.

Table 1: Names and Contents of Toxic or Hazardous Substances or Elements

表1：有毒有害物质或元素的名称及含量

部件名称 Part Name	有毒有害物质或元素 Toxic or hazardous Substances and Elements					
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr (VI))	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
印刷电路板组装 PC BD ASSY	X	0	0	0	0	0
面板 FACE PLATE	0	0	0	0	0	0
印刷电路板组装支持 PC BD ASSY SUPPORT	0	0	0	0	0	0
O 表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下 O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.						
X 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.						
环保期限 (EFUP) 的产品及其部件是每个列出的符号，除非另有标明。使用期限只适用于产品在产品手册中规定的条件下工作 The Environmentally Friendly Period (EFUP) for the product and its parts are per the symbol listed, unless otherwise marked. Use Period is valid only when the product is operated under the conditions defined in the product manual.						

James McFerrin
Environmental Compliance Manager PSG
T 512 832 3271 E james.mcferrin@emerson.com



Emerson Process Management
1100 W. Louis Henna Blvd.
Round Rock, TX 78681

Statement Regarding the China RoHS Compliance of Emerson Product – A6500-SR

Please refer to Table 1 for the names and contents of the toxic or hazardous substances or elements contained in Emerson products.

Table 1: Names and Contents of Toxic or Hazardous Substances or Elements

表1：有毒有害物质或元素的名称及含量

部件名称 Part Name	有毒有害物质或元素 Toxic or hazardous Substances and Elements					
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr (VI))	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
印刷电路板组装 PC BD ASSY	X	0	0	0	0	0
围堰 ENCLOSURE	0	0	0	0	0	0
硬件 HARDWARE	0	0	0	0	0	0
印刷电路板组装支持 PC BD ASSY SUPPORT	0	0	0	0	0	0
0 表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下 0: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.						
X 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.						
环保期限 (EFUP) 的产品及其部件是每个列出的符号，除非另有标明。使用期限只适用于产品在产品手册中规定的条件下工作 The Environmentally Friendly Period (EFUP) for the product and its parts are per the symbol listed, unless otherwise marked. Use Period is valid only when the product is operated under the conditions defined in the product manual.						

James McFerrin
Environmental Compliance Manager PSG
T 512 832 3271 E james.mcferrin@emerson.com



Emerson Process Management
1100 W. Louis Henna Blvd.
Round Rock, TX 78681

Statement Regarding the China RoHS Compliance of Emerson Product – A6500-RR

Please refer to Table 1 for the names and contents of the toxic or hazardous substances or elements contained in Emerson products.

Table 1: Names and Contents of Toxic or Hazardous Substances or Elements

表1：有毒有害物质或元素的名称及含量

部件名称 Part Name	有毒有害物质或元素 Toxic or hazardous Substances and Elements					
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr (VI))	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
印刷电路板组装 PC BD ASSY	X	0	0	0	0	0
围挡 ENCLOSURE	0	0	0	0	0	0
硬件 HARDWARE	0	0	0	0	0	0
印刷电路板组装支持 PC BD ASSY SUPPORT	0	0	0	0	0	0
O 表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下 O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.						
X 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572						
环保期限 (EFUP) 的产品及其部件是每个列出的符号，除非另有标明。使用期限只适用于产品在产品手册中规定的条件下工作 The Environmentally Friendly Period (EFUP) for the product and its parts are per the symbol listed, unless otherwise marked. Use Period is valid only when the product is operated under the conditions defined in the product manual.						

James McFerrin
Environmental Compliance Manager PSG
T 512 832 3271 E james.mcferin@emerson.com



Emerson Automation Solutions
1100 W. Louis Henna Blvd.
Round Rock, TX 78681

Statement Regarding the China RoHS Compliance of Emerson Product - A6500-FR

Please refer to Table 1 for the names and contents of the toxic or hazardous substances or elements contained in Emerson products.

Table 1: Names and Contents of Toxic or Hazardous Substances or Elements

表1：有毒有害物质或元素的名称及含量

部件名称 Part Name	有毒有害物质或元素 Toxic or hazardous Substances and Elements						
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr (VI))	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)	
印刷电路板组装 PC BD ASSY	X	0	0	0	0	0	25
硬件 HARDWARE	0	0	0	0	0	0	EF
○ 表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下 ○ Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.							
X 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.							
环保期限 (EFUP) 的产品及其部件是每个列出的符号。除非另有标明，使用期限只适用于产品在产品手册中规定的条件下工作 The Environmentally Friendly Period (EFUP) for the product and its parts are per the symbol listed, unless otherwise marked. Use Period is valid only when the product is operated under the conditions defined in the product manual.							

James McFerrin
Environmental Compliance Manager
Systems and Solutions
T: 512 832 3271 E: james.mcferrin@emerson.com



Emerson Automation Solutions
1100 W. Louis Henna Blvd.
Round Rock, TX 78681

Statement Regarding the China RoHS Compliance of Emerson Product - A6500-PE

Please refer to Table 1 for the names and contents of the toxic or hazardous substances or elements contained in Emerson products.

Table 1: Names and Contents of Toxic or Hazardous Substances or Elements

表1：有毒有害物质或元素的名称及含量

部件名称 Part Name	有毒有害物质或元素 Toxic or hazardous Substances and Elements						
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr (VI))	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)	
印刷电路板组装 C PC BD ASSY C	X	○	○	○	○	○	○
印刷电路板组装 PC BD ASSY	X	○	○	○	○	○	○
硬件 HARDWARE	○	○	○	○	○	○	○
○ 表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下 ○: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.							
X 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572							
环保期限 (EFUP) 的产品及其部件是每个列出的符号，除非另有标明。使用期限只适用于产品在产品手册中规定的条件下工作 The Environmentally Friendly Period (EFUP) for the product and its parts are per the symbol listed, unless otherwise marked. Use Period is valid only when the product is operated under the conditions defined in the product manual.							

James McFerrin
Environmental Compliance Manager
Systems and Solutions
T 512 832 3271 E james.mcferrin@emerson.com

A

Card related system events

The possible system events provided by the A6500-TP card are listed in [Table A-1](#). See column **Cross reference / Note** for further event related information. See AMS Machine Studio – General Functions manual for a common description of the system events.

Table A-1: Card events

Event	Cross reference / Note
Alarm entered	Digital outputs
Alarm left	
Channel OK entered	Channel OK supervision
Channel OK left	
Digital output x ¹ on (Hardware)	Digital outputs
Digital output x ¹ off (Hardware)	
Digital output y ² on (Software)	
Digital output y ² off (Software)	
Sensor OK left	Channel OK supervision
Sensor OK entered	
Temperature danger alarm entered	Channel OK supervision, see Overview for alarm indication
Temperature danger alarm left	
Temperature alert alarm entered	
Temperature alert alarm left	
Card starts up	-/-
Card started up successfully	-/-
Warm start finished	Software initialized start of the card is completed
Card reboots	-/-
Card configuration error	-/-
Bus address assigned successfully	Automatically assigned bus address for communication with A6500-CC card.
Bus address assigned failed	
Connection to A6500-CC established	-/-
Connection to A6500-CC lost	-/-
Mismatched checksum detected (package re-sent)	If the event appears only once, then resending solved the issue. If the event appears more often, contact support, see Technical support .
Card configured and rebooted	Send a configuration

Table A-1: Card events (continued)

Event	Cross reference / Note
Card configured	
Reset min/max entered	Online commands
Reset min/max left	
EEPROM error	Replace the card, if this does not solve the problem, contact support, see Technical support .
ADC error	
Reset Latch DO x ³ entered	Digital inputs , Online commands
Reset Latch DO x ³ left	
Bypass CH x ⁴ activated	Bypass
Bypass CH x ⁴ deactivated	

1 x = 1 to 6

2 y = 7 to 16

3 x = 1 to 16

4 x = 1 to 4

Index

A

A6500-CC [13, 18](#)
A6500-CP [13, 18](#)
A6500-xR [13, 16](#)
AMS Machine Studio [16](#)
Application [13](#)

B

Basic [31](#)
Bypass [75](#)

C

Calculation [44, 63](#)
Card replacement [77](#)
CCC Certification [10](#)
Check [78](#)
Close [31](#)
Cold junction compensation [39](#)
Commissioning [16](#)
Configuration [18](#)
Configuration offline [18](#)
Configuration online [19](#)
Configuration report [28](#)
CSA [16](#)
Current output [46](#)

D

Details [61](#)
Digital input [43](#)
Digital output [48](#)
Disposal [9](#)

E

ESD [12](#)

F

Front view [14](#)

H

hot-swappable [16](#)

I

Installation [16](#)

K

Key-switch [19, 20](#)

L

LED [67](#)

M

Maintenance [80](#)
Modbus [13](#)

N

New configuration [25](#)

O

OK LED [74](#)
Online view [56](#)
OPC UA [13](#)
Overview [57](#)

P

Process values [73, 80](#)

R

Redundancy [20](#)
Reload [26](#)
Reset, Factory default [78](#)
Ribbon command bar [25](#)
RTD [36, 68, 79](#)

S

Send & close [25](#)
Sensor input [32](#)
Show History/Drafts [29](#)
Side view [13](#)
System program status [19, 20](#)

T

Technical data [81](#)
Technical support [8](#)
Temperature measurement [68](#)
Thermocouple [33, 78](#)

Thermocoupler **70**

Time data **63**

Emerson
12001 Technology Drive
Eden Prairie, MN 55344 USA
T 1(952)828-3000
www.Emerson.com

Emerson
835 Innovation Drive
Knoxville, TN 37932 USA
T +1 865-675-2400
F +1 865-218-1401
www.Emerson.com

Emerson
Jöbkesweg 3
48599 Gronau
Germany
T +49 2562 709 0
F +49 2562 709 401
www.Emerson.com/ams

©2025, Emerson. All rights reserved.

The contents of this publication are presented for informational purposes only, and while diligent efforts were made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the designs or specifications of our products at any time without notice.

The Emerson logo is a trademark and service mark of Emerson Electric Co. The AMS logo is a mark of one of the Emerson family of companies. All other marks are the property of their respective owners.

